


XTS MAINTENANCE CONTROL

User's Guide

Version 8



E-Comm Pty Ltd PO BOX Q1299 QVB, SYDNEY, NSW, AUSTRALIA, 1230 International Tel: + 61 417 968846, Australia Tel: 0417 968846 Facsimile +61 (0)2 9225 9034

CONTENTS

FEATURES AND BENEFITS	•••••	3
ICONS		3
ABOUT THIS SOFTWARE		3
COMPUTER REQUIREMENTS		4
CONVENTIONS	•••••	4
INSTALLATION	• • • • • •	4
GETTING STARTED		4
USING THE MAINTENANCE PROGRAM	•••••	5
The Aircraft File	6 . 9 18 21 23 24 32	35
Charge Out Parts Inventory Maintenance Customers Reports	41	
INDEV		62

FEATURES AND BENEFITS

Features and Benefits of the "XTS" Program

- Collates and prints Airworthiness Directives and Bulletins as Worksheet or Logbook entry
- Simple access to stored Aircraft Maintenance Information
- Eliminates time consuming research of Airworthiness Information prior to scheduled or unscheduled Aircraft or Component maintenance
- Track Component times and early warning Report on Low Component times and Airworthiness Directives due.
- Provides record of Engine, Propeller and Maintenance Release expiry information
- Generates clear, easy to read, reports on all listed Aircraft.
- Provides easy access to Customer information and prints a full
- Customer listing
- Stores complete Inventory in Computer
- Collates and prints Invoices and Inventory information
- Maintains Source Traceability of all parts
- Find any part Invoiced to any Job
- Extensive StockTaking Functions as well as Data Export to other packages
- Instant Stock Valuation at cost and value
- Bin Location sorting to three levels

ICONS



The series of symbols used throughout the XTS User's Guide are:

a file kept in the PC's internal storage

hardcopy output from the XTS program to your PC's printer

indicates a special note about the item at which it is pointing

an IBM compatible PC

a floppy disk or CD ROM containing the "XTS" program

ABOUT THIS SOFTWARE

Ecomm Pty Ltd grants to the user, in consideration of payment of the licence fee, the right to display and use this software program. The ownership of this software belongs to Ecomm Pty Ltd. This licensed copy is not transferable, available for resale, loan, rent or lease. The licensee acknowledges that no promise, representation or warranty has been made or given by Ecomm Pty Ltd in relation to the profitability or other consequences obtained from the use of this software.

type at your keyboard these commands

COMPUTER REQUIREMENTS







An IBM compatible PC with a minimum of 2 megabytes of free disk storage space and a CD ROM drive. An optional Internet connection is desirable.

CONVENTIONS





The following terms apply to entering the information at your keyboard;

<DELETE> This means; Press the DEL key. <ESCAPE> This means; Press the ESC key. <INSERT> This means; Press the INS key.

<ENTER> This means; Press the ENTER key (or

RETURN key).

<CTL> + <ENTER> This means; Press the control key then

press the enter key while still holding the

control key.

INSTALLATION





Place the CD ROM containing the installation software into the CD ROM drive. Select the drive and run the "setup" file from the CD ROM.

A message will appear on the screen advising that installation of the program is being carried out. Follow the instructions in the installation program to install. After installation is complete you will be able to start the XTS system from a Desktop icon or Menu option.

After installation, a change to your configuration file may be necessary. the line: "FILES=100" must be added to the "Config.sys" file for DOS and Windows. For Windows NT the file is called "Config.nt".

GETTING STARTED





icon. The XTS icon resembles a cardfile.

> The program will now run and you will see the Main Menu on your screen.

USING THE MAINTENANCE PROGRAM

The screen now looks like this:



The Main Menu screen is presented with four choices. These can be selected by using the **UP** and **DOWN** arrow keys on your keyboard, then selecting the highlighted item by pressing your **<ENTER>** key. The four Main Menu items are explained next.


AIRCRAFT 🗀





When the highlighted item "AIRCRAFT" is selected from the Main Menu, by pressing **ENTER**>, the screen will show the table below with the Aircraft that the program has on file. Select one of the list by using your arrow keys to highlight the selection, or by typing the Call-sign, then press **<ENTER>** to view the data.

Highlight the Aircraft using the arrow keys and press <ENTER> to view or edit this Aircraft's file





ENTER NEW RECORD



To enter a **NEW RECORD** (a new Aircraft record), from the table of Aircraft, press **INSERT**>, and a blank record will be displayed, ready to enter Aircraft data. To return to the previous screen, press **<ESCAPE>**. To return to the Main Menu press **<ESCAPE>** again.

VIEW / EDIT RECORD *****



To view or edit an Aircraft Maintenance record, highlight an entry in the table list of Aircraft and press **<ENTER>**. The following screen will be displayed.

AIRCRAFT MAINTENANCE DATA				
	Record will be	Changed		
"F2" PRINT DATA SHEET	"F3" VIEW/EDI7	Γ AD's, SB's	"F4" COMPONENTS	
PRESS <ctrl+enter> T</ctrl+enter>	O SAVE THIS RECORD	ı	Update Today:21 NOV 94	
REGIST: THE MAKE: PIPER	MODEL: PA-3:	1-310 A	∕F SERIAL No:	
TOTAL TIME (T.T.A.F.): 11700 MAINT.REL: EXPIRES 11780.0			OTAL LANDINGS: SSUED AT:	
ENGINE No1 P/No : TSIO- ENGINE No2 P/No : LTSIO PROPELLER No1 P/No: HYC-1 PROPELLER No2 P/No: HYC-1	D-540-J2BD 123-RYC	S/No: 12345 S/No: 43215 S/No: EE-1234 S/No: EE-4321	O/HAUL AT: 12000.0 O/HAUL AT: 11900.0 O/HAUL AT:11859.4 O/HAUL AT: 12050.0	
No 1 ENGNE CYCLES: AND HOT SECTION DUE AT: No 2 ENGNE CYCLES: AND HOT SECTION DUE AT:				
ENG1 TO RUN: 300.0 ENG2 TO RUN: 200.0	HOT SECTION HOURS HOT SECTION HOURS	·•	PROP1 TO RUN: 159.4 PROP2 TO RUN: 1150.7	
CTRL+ENTER To SAVE and NEX	T Screen	ESC To EXT	Γ Last Update:21/11/94	

HOT KEY FEATURES

The **HOT KEY** features provide access to XTS's most powerful functions

- F2 Pressing the "F2" HOT KEY on your keyboard will send the selected Aircraft's data screen to your printer as, SPECIFICATION PRINTOUT SHEET.
- F3 Pressing the "F3" HOT KEY on your keyboard will open this Aircraft's Directives, Bulletins and Inspections menu.
- F4 Pressing "F4" HOT KEY will display this Aircraft's Component data information menu.

VIEW MORE DATA



By pressing **CTL** + **ENTER>** the next screen containing more Aircraft Specification data will be displayed.

PRESS <CTL+ENTER> TO SAVE THIS PAGE AND RETURN TO MAIN MENU

AVIONICS:

Record will be Changed

VHF : KING 7777 OTHER: KING 1234 : CODAN 2000 DME : INTER.KING : KING 7777

GLIDE : YES GPS : GARMIN 100

RADAR: STORMSCOPE ELT : YES TRANSPONDER ALTITUDE ENCODER: YES

FIRE EXT.: BCF 1.5 KG AUTOPILOT: CENTURY IV

COLOR Inside: ASH GREY

Outside: PALAMINO WHITE/ACAPULCO GOLD NOTES: RECENT MAJOR INTERIOR REFIT TO EXECUTIVE CLASS, FOR EXEC. CHARTER "F2" Print Blank Data Entry Form

PRINT BLANK FORM



Pressing the "F2" HOT KEY from the previous screen will send a blank form directly to the printer. The form can be used to record the details of an Aircraft for later entry into the Computer. The printout for entering the Aircraft Data is shown below.

BLANK



Enter the Information on the Aircraft for inclusion in the Database record CALLSIGN: A/C MAKE: A/C MODEL: SER No: TTAF: M/R EXPIRY HOURS: M/R EXPIRY DATE: AIRFRAME PRESS CYCLES: TOTAL LANDINGS: ENGINE No1 O/HAUL AT: S/No: P/No: ENGINE No2 O/HAUL AT: S/No: P/No: PROP No1 O/HAUL AT: P/No: S/No: PROP No2 S/No: O/HAUL AT: P/No: ENGINE CYCLES: ENG No2: ENG No1: HOT SECT DUE: ENG No1: ENG No2: AVIONICS: VHF OTHER \mathbf{HF} DMENAV **GPS** GLIDE ELT RADAR TRNSPONDER: ENCODER: FIRE EXTINGUISHER: AUTOPILOT COLOR Inside: Outside:

RETURN TO MENU



Press **<CTRL>** + **<ENTER>** to save any changes that are made or continue to press **<ENTER>** until the Aircraft Listing is displayed. Pressing **<ESCAPE>** from the Aircraft Listing Table will redisplay the Main Menu.

"F2" PRINTOUT



By pressing the "F2" HOT KEY from the AIRCRAFT MAIN-**TENANCE DATA** screen, the Aircraft Data file is sent to the printer directly, giving a printout of the Aircraft Specifications.

AIRCRAFT SPECIFICATION | **≜**



AIRCRAFT SPECIFICATION DATA

This Information reflects the status of the Aircraft at the last record ammendment. Any data must be clarified against the current maintenance release and the log book entries. Date this record last ammended: 26/08/00 This Report printed on 9 DEC 2000

MODEL: PA-31-310 CALL-SIGN: QAA MAKE: PIPER

TOTAL TIME: 5079.7 M/R EXPIRY HOURS: 11800.0 M/R EXPIRY DATE: 4/12/2000 AIRF.PRESS.CYCLES: TOTAL LANDINGS:

Engine No1 P/No: TSIO-540-J2BD Engine No2 P/No: LTSIO-540-J2BD S/No: 12345 O/HAUL DUE: 12000.0 S/No: 54321 O/HAUL DUE: 11900.0 Prop No1 P/No : HYC-123-RYC S/No: EE-12345 Prop No2 P/No : HYC-123-LYC S/No: EE-4321 O/HAUL DUE: 12050.7

No 1 ENGINE CYCLES: AND HOT SECTION DUE: No 2 ENGINE CYCLES: AND HOT SECTION DUE:

ENG1 TO RUN: 2471.6 HOT SECTION HOURS TO RUN PROP1 TO RUN: 2923 ENG2 TO RUN: 3018.3 HOT SECTION HOURS TO RUN: PROP2 TO RUN: 2923

AVIONICS: VHF : I

AUTOPILOT: CENTURY IV

: KING 777 NAV KING 777 OTHER CODAN 2000 : INT. KING HF DME GPS : GARMIN 100 GLIDE : YES FLT · YES RADAR · STORMSCOPE

ENCDR : YES

Outside: PALAMINO WHITE/ACAPULCO GOLD COLOR Inside: ASH GREY

ADDITIONAL NOTES: RECENT MAJOR INTERIOR REFIT TO EXECUTIVE CLASS, FOR EXEC. CHARTER

"F3" AD INSPECTIONS



Pressing the "F3" HOT KEY from the AIRCRAFT MAINTE-NANCE DATA screen, will display the Airworthiness Directives, Service Bulletins and Special Inspections Menu for this Aircraft.

FIRE EXTINGUISHER: BCF 1.5 KG

"F4" COMPONENTS



Pressing the "F4" HOT KEY from the AIRCRAFT MAINTE-NANCE DATA screen, will display the Component Menu for this Aircraft.

AIRWORTHINESS DIRECTIVES



SELECT AD MENU Pressing the "F3" HOT KEY from the AIRCRAFT MAINTE-NANCE DATA screen, will display a Screen allowing the user to choose Recurring or Non-Recurring Airworthiness Directives or Inspections.

AIRWORTHINESS DIRECTIVES - SERVICE BULLETINS RECURRING NON-RECURRING

Press Escape to Return to the Menu


Highlight using the arrow keys and press <ENTER> to select Recurring or Non-Recurring ADs or SBs.

RECURRING AIRWORTHINESS DIRECTIVES

RECURRING



Highlighting and selecting **RECURRING** will display the Recurring Airworthiness Directives, Service Bulletins and Special Inspections Menu for this Aircraft.



VIEW AD's, SB's DUE

SELECTMENU OPTION



Highlighting and selecting the menu option VIEW ADs SBs DUE, will display a Search Filter Screen which allows entry of the range of values for the Inspections to be located. Enter the HOURS, CYCLES and **DAYS** due, and a Category of Inspection. eg ALL, AIRFRAME, ENGINE or ELECTRICAL/RADIO.

SEARCH FILTER



SPECIFY SEARCH RANGE FOR AD's, SB's AND INSPECTIONS DUE				
"ENTER" FOR SEARCH	"ESC" RETURN TO MENU			
ENTER THE HOURS RANGE FOR THE AD S	SEARCH: DUE IN THE NEXT 200 HOURS			
ENTER THE DAYS RANGE FOR THE AD SE	ARCH: DUE IN THE NEXT 365 DAYS			
ENTER A/FRAME CYCLES FOR THE AD S	EARCH: DUE IN THE NEXT 100 CYCLES			
ENTER ENGINE CYCLES FOR THE AD S	EARCH: DUE IN THE NEXT 100 CYCLES			
ENTER THE CATEGORY FOR THE AD SEARCH: ALL AIRF ENG1 ENG2 EI&R				
ALL				
SELECTING "0" FOR SEARCH FILTER WILL DISPLAY OVERDUE ITEMS				
Press ESCAPE To Return to MENU				

SEARCH RESULTS



After a Search Filter has been set, Pressing **ENTER**> will display the following **MENU**. This **MENU** will give the option of **VIEWING** or **PRINTING** the filter results OR listing the filter results for **UPDAT-ING** of the compliance times.

HIGHLIGHT MENU OPTION AND PRESS ENTER
VIEW AND PRINTOUT ADs
MANUAL UPDATE ADs FOR
SELECTED PERIOD
AUTOMATICALLY UPDATE ADs FOR
SELECTED PERIOD
Press ESCAPE to Retun

VIEW / PRINT SEARCH

By selecting the **VIEW AND PRINTOUT ADs** option from the **MENU** above the following Table is displayed with the listed AD's and Inspections that fall inside the Search Filter Limits.

AIRWORTHINESS DIRECTIVES, SE	RVICE BULLETINS AND I	NSPECTION	vs
CALL-SIGN QAA MAKE PIPER M 200 HOURS, 365 DAYS, 100 A/F CYC	ODEL PA-31-310 T LES, 0 ENG CYCLES C		
"F2" WORKSHEET "F3" PRINT THIS LIST	"F4" PRINT COST "	'ESC" NEW	SEARCH
AD/SB REF & DESCRIPTION CATEGO PERIOD: DAYS, HRS, A/F CYC, ENG CYC	·	CYCLES AIRFRAME	1-1
RAD/43 FI&R TESTING AND CALIBRATION OF ALTI ENCODE	R 25/12/1995 0.00	0	0
ELECT/46 PARA 1 ENG1 MAGNETO POINTS INSPECTION	/ / 11750.00	0	0
GEN/6A AIRF			

PRINT SEARCH RESULTS



From the Table Listing a **PRINTOUT** is available in **TWO** formats. The List of AD's and Inspections can be printed as a **LOGBOOK WORKSHEET**, called the **AIRWORTHINESS DIRECTIVE AND SPECIAL INSPECTION COMPLIANCE SHEET**, by pressing the **HOT KEY "F2"**, which provides an area for **LAME CERTIFICATION**, **OR** printed as a Listing as it is displayed on the Screen by pressing **HOT KEY "F3"**.

F2 WORKSHEET PRINTOUT

-
=
_
_

AIRWORTHINESS DIRECTIVE AND SPECIAL INSPECTION COMPLIANCE SHEET CATEGORY ALL Call-Sign: LPA Aircraft Type: CESSNA C172A Job Number:..... Task No: Landings: Prepared by:..... Hours: WORK REQUIRED: RAD/50 AME FUNCTIONAL TESTING OF THE ELT BEACON LAME ACTION TAKEN: LIC No TASK No: DATE: S/No on P/No S/No OFF R/N No CATEGORY CO-ORDINATOR CERTIFICATION: I hereby certify for the completion and co-ordination of the above mentioned maintenance. Certifications are pursuant to

LAME: DATE: DATE:

F4 COSTING REPORT



Selecting the "F4" HOT KEY from the AD screen will display a costing report. With the COSTING REPORT on screen a printout can be obtained by pressing "F2".

AIRWORTHINESS DIRECTIVES, SERVICE BULLETINS & INSPECTIONS CALLSIGN AAA MAKE PIPER MODEL PA42 TOTAL TIME 11700.0 0 HOURS, 0 DAYS, 0 A/F CYCLES OR 0 ENG CYCLES CATEGORY ALL AIRWORTHINESS COMPLIANCE COSTING FOR THE LISTED ADS PRESS "F2" FOR THIS COSTING PRINTOUT AD\ENG\4 ENGINE OVERHAUL \$12,700.00 AD\INST\8 INSTRUMENT CALIBRATION \$600.00 AD\RAD\43-47 TRANSPONDER CHECKS \$315.00 AD\PROP\1 PROPELLOR OVERHAUL \$1450.00

COSTING PRINTOUT

Pressing the $HOT\ KEY\ ''F2''$ will direct the table displayed above to the printer

AD COSTING REPORT



THIS REPORT LISTS THE AIRWORTHINESS DIRECTIVE LISTING AND COST TO PERFORM FOR EACH INSPECTION. MULTIPLE OCCURANCES OF THE LISTED DIRECTIVES ARE NOT SHOWN BUT MAY BE REQUIRED TO BE CARRIED OUT WITHIN THE SELECTED PERIOD

AIRCRAFT REGISTRATION: AAA AIRCRAFT: PIPER PA-42 TTAF: 5079.0
THESE DIRECTIVES WILL OCCUR IN THE PERIOD

100 HOURS OR 0 DAYS 0 A/F CYCLES, 0 ENG CYCLES CATEGORY: ALL

REFERENCE NUMBER AND DESCRIPTION OF INSPECTION AD COST

AD/ENG/4

ENGINE OVERHAUL \$12,000.00

AD\INST\8

INSTRUMENT CALIBRATION \$700.00

AD\PROP\1

PROPELLOR OVERHAUL \$1450.00

UPDATE AD's



Selecting MANUAL UPDATE ADs FOR SELECTED PERIOD

will list those ADs selected by the search filter and display them ready for editing of the compliance times and cost. By pressing **<ENTER>** on the highlighted ADs their compliance times and cost is displayed ready for editing. As soon as the AD has been edited, the updated information is then redisplayed showing the ADs that remain inside the filter specification.

Press ENTER on the Highlighted AD to Enter the NEW Compliance Time/Date				
REFERENCE AND DESCRIPTON	DATE DUE	TTAF DUE	CYCLES AIRFRAME	
AD\ENG\4 ENGINE OVERHAUL	0/00/0000	6744.7	0	0
AD\INST\8 INSTRUMENT CALIBRATION	7/12/1995	0.0	0	0
AD\PROP\I PROPELLER OVERHAUL	0/00/0000	6720.0	0	0
	Press ESCAPE to F	Return		

EDIT DUE TIMES



Pressing **<ENTER>** on the highlighted Inspection will display the editing screen below. The Inspections due can be edited on the compliance times, cycles due, date due and cost field only.

MODIFY THIS INSPECTION TO SHOW NEXT COMPLIANCE

REFERENCE : AD\ENG\4

DESCRIPTION: ENGINE OVERHAUL INSPECTION PERIOD: 100 HOURS 365 DAYS

> AIRFRAME CYCLES ENGINE CYCLES

DATE DUE AT: 0/0/0000 TTAF DUE AT: 6744.7 A/F CYCLES DUE AT: ENG.CYCLES DUE AT:

COST: \$15,000

Record will be Changed

VIEW ALL ADS SBS IN THIS AIRCRAFT

SELECT MENU OPTION Highlighting and selecting the menu option VIEW ALL ADs SBs DUE FOR THIS AIRCRAFT, will display a report of ALL ADs, selected by CATEGORY, for the selected Aircraft. To obtain a PRINT-**OUT** of those **ADs** and **SBs**, ensure the printer is on and press the HOT KEY F2.

AIRWORTH	INESS DIRECTIVES MAKE PIPER	•			- 1
"F2" TO PRINT THIS LIST "ESC" TO EXIT					
AD/SB REF.	CATEGORY			CYCLES	DUE
DESCRIPTION		DATE DUE	TIME DUE	AIRFRAME I	ENGINE
RAD/43 TESTING AND CALIB	EI&R RATION OF ALTITUD	25/12/1995 E ENCODER	0.00	0	0
ELECT/46 PARA 1 MAGNETO POINTS I	EI&R	$I \cdot I$	11750.00	0	0
GEN/6A	AIRF LINE AND SELECTION	/ / N INSP	11800.00	0	0
PA28/28#2 CONTROL COLUMN	AIRF NINSPECTION	15/03/1996	11800.00	0	0

ENTER OR CHANGE ADS AND SBS

EDIT / CHANGE AD



By highlighting and selecting the menu option ENTER OR CHANGE ADs AND SBs from the Airworthiness Directives Menu, the AD Inspection Library will be opened for editing or inserting new Inspections, Airworthiness Directives or Service Bulletins.

AIRWORTHINESS DIRECT CALL-SIGN: LPA MAKE: CE						
<enter> CHANGE INSP</enter>	<inser< td=""><td>T>ADD INSP</td><td></td><td></td><td><delete>DE</delete></td><td>LETE INSP</td></inser<>	T>ADD INSP			<delete>DE</delete>	LETE INSP
AD/SB REF and DESCRIPTION CYCLES DUE						
	CATEGORY	DATE DUE	TIME	DUE	AIRFRAME	ENGINE
RAD/50 FUNCTIONAL TESTING O	EI&R F THE ELT BE	ACON /	5300	.00	0	0
ELECT/46#6 PARA 1 MAGNETO POINTS INSPE	EI&R CTION	1 1	5025	.00.	0	0
CESSNA170/19#1 STALL WARNING HORN T	EI&R TEST	1 1	5025	00.8	0	0
GEN6A ALTERNATE STATIC LINE	EI&R SELETION II	/ / NSP.	5300	00.0	0	0

EDIT AN INSPECTION



By highlighting an Inspection and pressing the **<ENTER>** key TWICE from the AIRWORTHINESS DIRECTIVE, SERVICE BULLETIN AND INSPECTION screen, the next screen is displayed with the "Record will be Changed" message. This allows editing of the highlighted inspection contained in the Aircraft record.

AIRWORTHINESS DIRECTIVES, SERVICE BULLETINS AND INSPECTIONS FOR CALL-SIGN: LPA RECURRING INS: ADD AD/SB DRKSHEET AIRWORTHINESS DIRECTIVES - SERVICE BULLETINS AD/SB REFEREN TIME DUE AIRCRAFT RECORD DESCRIPTION Record will be Deleted RAD/50 REF: RAD/50 FUNCTIONAL INSP: FUNCTIONAL TESTING OF THE E.L.T. BEACON 5300.00 INSPECTION PERIOD: 100 HOURS ELECT/46#6 PAF 365 DAYS MAGNETO P 5025.00 AIRFRAME CYCLES CESSNA170/19# ENGINE CYCLES 5025.00 STALL WAR TOTAL TIME = 5000.0 TOTAL CYCLES: GEN6A CALL SIGN: LPA ALTERNATE 5300.00 DATE DUE: GEN/37#5 A/F CYCLES DUE: ENG CYCLES DUE: EMERGENCY TTAF DUE: 5300.0 0.00 CATEGORY: AIRF ENG1 ENG2 EI&R COST: \$175.00

DELETE a record by simply highlighting and pressing <DELETE>. Your action will prompt the program to confirm the deletion



By highlighting an inspection and selecting **DELETE**> from the AIRWORTHINESS DIRECTIVE, SERVICE BULLETIN AND **INSPECTION** screen, the same screen as above is displayed. You will be prompted to press **<ENTER>** which will erase the highlighted inspection from the Aircraft Record.


ADD AN INSPECTION




By selecting **INSERT**> from the **AIRWORTHINESS DIREC**-TIVE, SERVICE BULLETIN AND INSPECTION screen, the AD/SB inspection Library will be displayed.

AD/SB/INSPECTION LIBRARY

Highlight the Inspection using the arrow keys and press <ENTER> to ADD an AD/SB to the Aircraft's







CAUTION



WARNING: Any deletion of an inspection listed in the LIBRARY of Airworthiness Directives will erase this inspection from every other Aircraft Record, leaving a blank space in the Aircraft Record.

LOOKUP INSPECTION



Typing the first few letters of the Inspection will cause the **LOOKUP** feature to automatically locate the Inspection you need. When it is highlighted simply press the **<ENTER>** key and this next screen will prompt for confirmation to add this inspection to the current Aircraft Record.

		<u>-</u>			
AIRWORTHINES	AIRWORTHINESS DIRECTIVES, SERVICE BULLETINS AND INSPECTIONS FOR				
CALL-SIGN: LPA	DESIDDRIS	156.4			
INS: ADD AD/SB	RECURRING	DRKSHEET			
AD (CD DEEEDEN	AIRWORTHINESS DIRECTIVES - SERVICE BULLETINS				
AD/SB REFEREN	AIRCRAFT RECORD	TIMEDUE			
DESCRIPTION	Record will be Added				
RAD/50	REF: RAD/50				
FUNCTIONAL	INSP: FUNCTIONAL TESTING OF THE E.L.T. BEACON	5300.00			
ELECT/46#6 PAR	INSPECTION PERIOD: 100 HOURS				
MAGNETO P	365 DAYS	5025.00			
CESSNA170/19#	AIRFRAME CYCLES	2022200			
	ENGINE CYCLES				
STALL WAR	TOTAL TIME = 5000.0 TOTAL CYCLES:	5025.00			
GEN6A					
ALTERNATE	CALL SIGN: LPA	5300.00			
GEN/37#5	DATE DUE: / /				
EMERGENCY	A/F CYCLES DUE: ENG CYCLES DUE:	00.0			
EMERGENCI	TTAF DUE: 5300.0	0.00			
	CATEGORY: AIRF ENG1 ENG2 EI&R				
	COST: \$175.00				

ENTER DATE & TIME



The display now prompts for the **DATE DUE**, A/F CYCLES, EN-GINE CYCLES, TIME DUE and the CATEGORY to be entered before the entry can be added to the Aircraft Record.

ADDING INSPECTIONS TO LIBRARY



From the Following Airworthiness Directives **LIBRARY** screen, press <INSERT> to add a new Airworthiness Directive, Service Bulletin or Inspection.

AIRWORTHINESS DIRECTIVES - SERVICE BULLETINS - SPECIAL INSPECTIONS ————————————————————————————————————				
<enter> CONFIRM/PLACE</enter>	<insert> ENTER NEW INSP.</insert>	 DELETE INSP.		
A/D-S/B-INSPECTION REFERE	NCE DESCRIPTION			
CESSNA170/53#2 CESSNA170/19#2 BEECH36/14#2 GEN6A GEN37#5 HO SE/2#3 HO SE/3#5 RAD/50 INST/8#5 LYC/78#5 ELECT/46#6 ELECT/46#6 ELECT/46#6 ENG/4	CHECK WEAR ON THE SEAT STALL WARNING HORN TES WING MAIN SPAR CAPS; CO ALTERNATE STATIC LINE AN EMERGENCY EXIT FOR COR PRESSURE TEST/REPLACEMI PRESSURE TEST/REPLACEMI TESTING AND CALIBRATION TESTING AND CALIBRATION VERNATHERM VALVE INSPE MAGNETO POINTS INSPECT MAGNETO COMING IN SPER	TO DEFINITION OF THE PROPERTY OF A LITTUDE ENCODER NO FOR THE PROPERTY OF THE		

ADDING RECORD



Pressing **<INSERT>** will display the next screen.

AIRWORTHINESS DIRECTIVE - SERVICE BULLETIN LIBRARY

Record will be Added

REFERENCE:

DESCRIPTION:

INSPECTION PERIOD: DAYS

HOURS

AIRFRAME CYCLES ENGINE CYCLES

After the AD, SB or Inspection reference number, description and inspection period has been entered, this Inspection will be added to the Library of Inspections, Airworthiness Directives and Service Bulletins.

CHANGE INSPECTION



To change any Airworthiness Directive, highlight the inspection, and press **<ENTER>** from the Library list screen. To delete any of the inspections in the Library list, highlight the inspection to be deleted and press **<DELETE>**.

When deleting or changing any Airworthiness Directive, a screen is displayed to prompt you for your action. A message above the Inspection Information will tell you whether you are about to delete or change the record.

CAUTION



WARNING: ANY DELETION OR EDITING OF AN INSPECTION LISTED IN THE INSPECTION LIBRARY WILL ERASE OR CHANGE THIS INSPECTION FROM EVERY LINKED AIRCRAFT RECORD.

NON - RECURRING AIRWORTHINESS DIRECTIVES

NON - RECURRING

AIRWORTHINESS DIRECTIVES - SERVICE BULLETINS NON - RECURRING INSPECTIONS

Highlight and Press <ENTER> to select Menu option

VIEW NON-RECURRING AD's, SB's

IMPORT/EDIT NON-RECURRING AD's, SB's

Press Escape to Return to the MENU

SELECTMENU OPTION



Selecting VIEW NON RECURRING AD's, SB's from the NON **RECURRING** Menu, will display the following Table list of only those non-recurring inspections linked to the selected Aircraft.

NON-RECURRING AIRWOR		ESS DIRECT IODEL PA-		LLETINSAL TIME 11700.0
"F2" TO PRINT THIS LIST			"ESC" TO EXI	
AD/SB REF. DESCRIPTION	ACTI	ON TAKEN	COMPLIED ON	COMPLIED AT
PA/42/17 M.L.G. ACTUATOR BOLT	N/A M	Iod.	15/03/1992	9098.7

PRINT NON RECURRING AD LIST



By Pressing the HOT KEY F2, a printout list of the NON-**RECURRING AD** and **SB's** will be sent to the printer.

ADD NON RECURRING AD TO AIRCRAFT RECORD



Selecting IMPORT/EDIT NON RECURRING AD's, SB's from the NON RECURRING MENU will display the following Import and Edit Screen. Only those Inspections that are linked to the Aircraft record are visible. To EDIT a current NON RECURRING Inspection, press **<ENTER>** TWICE and the Inspection will be displayed to change. To IMPORT a NON RECURRING Inspection, press **<INSERT>** and a list is displayed of the Inspections already entered into the LIBRARY. Highlighting required Inspection and pressing **<ENTER>** will **ADD** this Injection to the Aircraft Record and prompt for the DATE and HOURS that the Inspection was complied with.

NON-RECURRIT	NG AIRWORT MAKE PIPER	HINESS DIF MODEL				LETINS L TIME 11700.0
<insert> ADD RECORD</insert>	<enter> EDI</enter>	T HIGHLIGH	ITED	<delete> D</delete>	ELETI	E HIGHLIGHTED
AD/SB REF. DESCRIPTI	on A	ACTION TAI	KEN	COMPLIE	ON	COMPLIED AT
PA/42/17 M.L.G. ACTUATOR BOL	T P	N/A Mod.		15/03/199	92	9098.7

ADD NEW NON RECURRING AD TO LIBRARY



From the **LIBRARY of NON RECURRING** Inspections, pressing <INSERT> will display a blank record, ready to enter details of a **NEW NON RECURRING** Inspection to be added.

COMPONENTS

COMPONENT MENU

Highlight with arrow keys

and <ENTER> to select

Component option



Pressing the 'F4' HOT KEY from the Aircraft Maintenance Data Screen, the following **SUB MENU** is displayed.

COMPONENT MENU VIEW COMPONENTS DUE VIEW ALL COMPONENTS ON THIS AIRCRAFT CHANGE OR ENTER NEW COMPONENT EXTENDED COMPONENT MAINTENANCE


Press Escape to Return to the MENU

VIEW COMPONENTS DUE



VIEW COMPONENTS DUE Selecting VIEW COMPONENT DUE from the above SUB MENU and pressing **<ENTER>** will display another **MENU** that allows entry of a **SEARCH FILTER**. Components can be located by **HOURS**, **DAYS** and **CYCLES** due and also allows the user to specify the **CAT-**EGORY Component to be displayed. The CATEGORY of COM-PONENT can be in the range covered by ALL, AIRFRAME, ENGINE 1 or ENGINE 2.

> The following Screen displays the COMPONENT SEARCH FIL-TER.



Enter the Hours, Days, Cycles and Category for the Search Filter and press <ENTER> to list selection

SEARCH FILTER RESULTS

After entering the HOURS, DAYS, A/F CYCLES, ENGINE CYCLES and CATEGORY for the required COMPONENT search, the following screen is displayed.

-	OMPONENTS IN T KE:DHC-CANADA I AYS OR 99999	MODEL:DHC6-310		22627.1 CYCLI	X130 ES: 34597 ORY ALL
"F2" PRINT WORKSH	EET "F3"	PRINT ALL DETA	ILS	"F4" PRINT TH	S LIST
COMPONENT	PART No SERIAL No	HOURS TO RUN	DAYS TO RUN	CYCLES AIRFRAME	DUE: ENGINE
L/H WING	C6W1001-27		N/A	71404	
R∕H WING	533-L27 C6W1001-27		N/A	66000	
COMPRESSOR STG.1	3013111 53B938		N/A	53436	
COMPRESSOR STG.2	3013712 8E812		N/A	47762	
COMPRESSOR STG.3	3011713		N/A	48762	
CT DISC	8E445 3013411	9865.1	N/A		
CT DISC	1X831 3013411		N/A	40169	
FUEL CONTROL UNIT	1X831 252440-4 A74219	3893.9	N/A		

Pressing the HOT KEY F2 will send the results of the SEARCH FILTER listing directly to the printer.

VIEW ALL COMPONENTS ON THIS AIRCRAFT

VIEW ALL COMPONENTS



Selecting the Menu Option VIEW ALL COMPONENTS ON THIS AIRCRAFT, will display the following table listing. Pressing the **HOT KEY F2** will send the Listing to the printer. The Components are sorted in the Listing by alphabetical occurance and then in order of Category. ie Airframe Items, followed by Engine1 items and then Engine2 items.

	ENTS LISTED FOR TH A/F CYCLES= 3459		X141
"F2" TO PRINT THIS LIST		"ESC" TO EXIT	
COMPONENT CAT PART No SERIAL No	HOURS DAYS TO RUN TO RUN		: ENG2
L/H WING AIRF C6W1001-27 533-L27 R/H WING AIRF	20711.	36807	
C6W1001-27 COMPRESSOR STG.1 ENG1	10371.	31403	
3013111 53B938 COMPRESSOR STG.2 ENG1	18894.	18839	
3013712 8E812 COMPRESSOR STG.3 ENG1	•	13165	
3011713 8E445		14165	

CHANGE OR ENTER NEW COMPONENT

NEW COMPONENT




To enter a **NEW** Component, select **CHANGE OR ENTER NEW COMPONENT** from the Component Menu. The following screen is displayed. Pressing <INSERT> will ADD a NEW Component, pressing **<ENTER>** will allow editing of the highlighted Component and pressing **<DELETE>** will erase the highlighted Component from the Aircraft record.

ENTER NEW COMPONENT(S)	FOR: CALL-	NEW COMPONENT SIGN AFM		ss ESC To EXIT
TTAF:	22627.1	CYCL	ES: 34597	
<insert> NEW RECORD <</insert>	ENTER> EDIT	HIGHLIGHTED	<pre><delete> DELET</delete></pre>	TE HIGHLIGHTED
LOC COMPONENT	SERIAL	HRS ON HRS DUE	DATE ON DATE DUE	CYCLES DUE AIRF. ENGINE
AIRF L/H WING	533-L27	20615.0	21/06/1998	71404
AIRF R/H WING		43339.0	2.2	66000
ENG1 COMPRESSOR STG.1	53B938	32999.0 22521.8 41521.8	5/05/1999	53436
ENG1 COMPRESSOR STG.2	8E812	41521.8 0.0 0.0		47762
ENG1 COMPRESSOR STG.3	8E445	0.0 0.0		48762
ENG1 CT DISC	1X831	22521.8 32492.2	2.2	
ENG1 CT DISC	1X831	0.0	3.3	40169
ENG1 FUEL CONTROL UNIT	A74219	0.0 22521.0 26521.0		

INSERT NEW COMPONENT



Pressing **INSERT**> will allow you to **ADD** a new Component in the Component entry format below. Selecting category with the keyboard arrow keys will allow sorting of the Components.



EDIT OR DELETE COMPONENT



Pressing **<ENTER>** or **<DELETE>** from the Table Listing will display a similiar screen to the one above. **<ENTER>** will allow editing of the current highlighted Component Record and **VELETE** will prompt confirmation of deletion of the currently selected Component Record.

EXTENDED COMPONENT MAINTENANCE





EXTENDED COMPONENT Selecting the EXTENDED COMPONENT MAINTENANCE option from the **COMPONENT** Menu will display a list of the components for the Selected Aircraft.

	IDED COMPONENT MAINTE	
CALL SIGN	AFM TOTAL TIME	22627.1
PART NUMBER	DESCRIPTION	SERIAL NUMBER
C6W1001-27	L/H WING	533-L27
C6W1001-27	R/H WING	
3013111	COMPRESSOR STG.1	53B938
3013712	COMPRESSOR STG.2	8E812
3011713	COMPRESSOR STG.3	8E445
3013411	CT DISC	1X831
3013411	CT DISC	1X831
252440-4	FUEL CONTROL UNIT	A74219
025323-101	FUEL PUMP	9124
3013176	IMPELLER	1B545
210625	OUERSPEED GOUERNOR	21331061
PT6A-27	POWER SECTION	42013P
8210-004	PROP. GOVERNOR	2456816
3022412	PT DISC	7E1175
CPW3019109	STARTER CONTROL	12073
23048-004M	STARTER GENERATOR	4772L
F2 to List All Co	omponents Times ENT	ER to View Record

DETAILED VIEW



Pressing **<ENTER>** on a highlighted component will display the following screen, showing a detailed view of the selected component. Pressing "F2" from the list of components for the selected Aircraft will produce a screen based listing of all the Components with expiry information.

		X140
CATEGORY: AIRF COMPONENT:L/H WING		DED COMPONENT MAINTENANCE PART No:C6W1001-27 SERIAL No:533-L27
TB Ret: Date New/OH: Date Fitted: Inst Last: Cycles On: TSO Inst: TSN Inst: Comp TTIS: Comp TSO: TT OH: TRet: TR Ret: Date Due Off:	22724.0 21/06/1998 20615.0 31154 0.0 2012.1 2012.1 43339.0 20711.9 43339.0	Time Before Overhaul Time Before Retirement Date New or Overhauled Date Fitted
F2 PRINT COMPONENT	INFORMATIC	ON

COMPONENT LIST



The Component Listing is shown below with expiry information in more detailed format.


F2 to Print	Listing	of the Comp	onents for	Callsign	AFM	ESC to Exit
Part Descr/No Serial No	TB OH TB Ret	Inst Last TSN Inst	Comp TTIS Comp TSO	TT OH TT Ret	TRem OH TR Ret	Date New/OH Date Due
L/H WING C6W1001-27 533-L27	0.0 22724.0	20615.0 0.0	2012.1 2012.1	43339.0	20711.9	//
R/H WING C6W1001-27	0.0 32999.0	0.0 0.0	22627.1 22627.1	32999.0	10371.9	//
COMPRESSOR STG.1 3013111 53B938	19000.0 19000.0	22521.8 0.0	105.3 105.3	41521.8 41521.8	18894.7 18894.7	5/05/1999 / /
COMPRESSOR STG.2 3013712 8E812	0.0 0.0	0.0 0.0	22627.1 22627.1			<i>;;</i>

CUSTOMERS


SELECT CUSTOMER



From the Main Menu, highlighting and selecting **CUSTOMERS** will display the screen below. As in the **AIRCRAFT** selection, a list is presented with the Customers records that are stored in the program.



DELETE a record by simply highlighting and pressing <DELETE>. Your action will prompt the program to confirm the deletion




VIEW / EDIT RECORD



To display and edit the Customer file, highlight the selected customer using your arrow keys, and press <ENTER>. A window will appear displaying the Customer record. The cursor will be flashing in the first entry, allowing you to overwrite the information. To return to the previous Customer table screen above, press <ESCAPE>.

Cursor will blink on first entry, ready to edit





Two lines reserved for your comment

ENTER NEW RECORD



To enter a **NEW RECORD** (a new Customer record), from the table of Customers, press **INSERT**, and a blank record will be displayed, ready to enter Customer data. To return to the previous screen, press **ESCAPE**. To return to the Main Menu press **ESCAPE** again.

REPORT




SELECT REPORT



From the Main Menu, highlighting and selecting **REPORT** will display this screen:

Highlight with arrow keys and <ENTER> to select Report type



The six selections are:

Operation / Schedule

Aircraft Major Component Times

Airworthiness Directives, Service Bulletins and Inspections

Components (ALL)

Customer Listing

Security

OPERATION / SCHEDULE



OPERATION/SCHEDULE | By highlighting and selecting OPERATION/SCHEDULE, from the **REPORT DATA** Menu and pressing **<ENTER>**, the program will display the following information.

OPERATION / SCHEDULE TIMES X153							
	PRESS F2 T	O PRINT		HIG	HLIGHT &	PRESS F3 T0) UPDATE
CALL SIGN	LASTTRIP DATE	SINCE MR HOURS	LANDING CYCLES	L-ENG CYCLES	R-ENG CYCLES	AIRFRAME CYCLES	AIRFRAME HOURS
AFM AFN AFO FET FHC FHF FIG FIC FIL FSC LCM YES	23/06/99 23/06/99 22/06/99 18/04/99 23/06/99 23/06/99 30/05/99 21/06/99 23/06/99 15/06/99 23/06/99	11 75 0 64 0 23 38 0 91 75 52 8	34597 22178 21150 42949 17042 7793 8899 12124 5513 25683 23701	10845 12724 1012 833 17042 7754 541 9472 4896 30750 12802	13532 10928 9666 833 7747 6320 541 8096 4164 9306 7856	34597 22178 21150 42949 17042 7793 8899 12124 5513 25683 23701	22627.1 13405.5 15475.9 18897.6 9406.0 4289.7 5677.3 3909.1 26840.2 11155.9 2599.4 19787.8 19447.1

The table above displays the hours and cycles information for the entire fleet at a glance. Individual aircraft records can be updated from this screen by pressing F3. Pressing F3 on a highlighted record will display the next screen, which allows the updating.

24 XTS User's Guide

Cí	UPDA ALL-SIGN: AFM		MES / FLIGHT I RAFT: DHC-CANA		
TRIPDATE 23/06/1999	TTAF 22627.1	P LANDINGS 34597	REUIOUS ===== A/F CYCLES 34597	LEFT STARTS 10845	RIGHT STARTS 13532
23/06/1999 22627.1 34597 34597 10845 13532 TRIPDATE: 0/00/0000 FLIGHT TIME: 0.0 LANDINGS: 0 A/F PRESSURE CYCLES: 0 LEFT ENGINE STARTS: 0 RIGHT ENGINE STARTS: 0					
COMPUTED TTAF 22627.1	TOTAL LANDI 34597	NGS TOT	NEW ===== AL A/F CYCLES	LEFT STARTS	RIGHT STARTS

By entering the prompted information, the Aircraft record can be updated and Component times and Airworthiness Directive times will automatically be adjusted.

AIRCRAFT / PROPELLER / ENGINE / MR

TIMESLEFT

By highlighting and selecting AIRCRAFT / ENGINE / PROPEL-LER / M-R from the REPORT DATA Menu and pressing <EN-TER>, the program will display the next screen.

	ENGINE PROPELLER AND MAINTENANCE RELEASE EXPIRY TIMES PRESS "F2" TO PRINT							
A/C	ENGINE No 1			1	ENGINE No2		MAINT	
CALL	ENGINE	HOT\TOP	PROPELLER	ENGINE	HOT\TOP	PROPELLER	REL.	
SIGN	HTR	HTR	HTR	HTR	HTR	HTR	DTR	
QAA	869.3	173.3	794.3	869.3	173.3	794.3	331	
QRC	1220.1	0.0	829.1	1220.1	0.0	829.1	185	
QUT	822.0	0.0	959.0	822.0	0.0	959.0	330	

EXPIRY PRINTOUT



By pressing the "F2" HOT KEY, a printout of the TIMES RE-**MAINING** is sent directly to the printer. This printout is shown below.



ENGINE PROPELLER AND MAINTENANCE RELEASE EXPIRY TIMES FLEET REPORT

This Report Printed on APR 24, 1996

	ENGINE No 1			EN			
A/C							MAINT
CALL	ENGINE	HOT\TOP	PROPELLER	ENGINE	HOT\TOP	PROPELLER	REL.
SIGN	HTR	HTR	HTR	HTR	HTR	HTR	DTR
LPA	100.0	245	1300.0	100.0	245	1300.0	232
QZT	345.0	38	345.0	345.0	38	345.0	18

AIRWORTHINESS DIRECTIVES

DIRECTIVES REPORT



By highlighting and selecting **AIRWORTHINESS DIRECTIVES**, from the REPORT DATA Menu and pressing <ENTER>, the program will display the following SUB MENU.

SUB MENU

AIRWORTHINESS DIRECTIVES, SERVICE BULLETINS AND OTHER INSPECTIONS

URGENT INSPECTION by DATE ACROSS FLEET

LIST OCCURANCES OF INSPECTION ACROSS FLEET

EDIT / DELETE / INSERT NEW AD OR SB

Press ESCAPE to return to MAIN MENU

The three Menu choices available are:

Urgent Inspection by Date, which shows all AD's List Occurances, which will find occurances of AD's and EDIT/DELETE/INSERT, which allows entry of AD's


INSPECTION BY DATE ACROSS FLEET

DATE DUE REPORT



From the **SUB MENU** above, by highlighting and selecting the first item, "URGENT INSPECTION by DATE ACROSS FLEET", the following report is displayed on the screen.

26 XTS User's Guide



DATE DUE PRINTOUT



To obtain a printout from your printer, make sure the printer is on and press the "F2" HOT KEY.

The printout obtained from the **DATE DUE** screen is shown below. Pressing **<ESCAPE>** will display the **REPORT SUB MENU**.



AIRWORTHINESS DIRECTIVES, SERVICE BULLETINS AND OTHER INSPECTIONS PRINTOUT IN ORDER OF DATE DUE This Report for all Aircraft on File Printout Date: APR 24,1995

CALLSIGN	DUE DATE	DESCRIPTION OF A/D, S/B OR INSPECTION
QZT LPA	21/05/1995 21/06/1995	EMERGENCY EXIT FOR CORRECT OPERATION EMERGENCY EXIT FOR CORRECT OPERATION

Page 1

LIST OCCURANCES OF INSPECTION

LOOKUP INSPECTION



By highlighting "LIST OCCURANCES OF INSPECTION" from the Airworthiness Directives sub-menu, and pressing **<ENTER>**, the following lookup screen is displayed. This allows you to choose what AD or Inspection that you want to list, for all Aircraft in the program.

Highlight with arrow keys or key-in and <ENTER> to select Inspection or AD to lookup



LOOKUP:					
CESSNA170/19#2					
CESSNA170/53#2					
ELECT/46#6					
ELECT/46#6 PARA 2					
ELECT/59					
ENG/4					
GEN/37#5					
GEN/6A					
HOSE/2#3					
HOSE/3#6					
INST/8#5					
INST/9#3					
LIFEJACKETS					
LYC/78#5					
LYC/78#5 PARA 2					
PROP/1					
RAD/43					
RAD/50					
ROTORBLADES CHECK 1					
PRESS <esc> RETURN TO MENU</esc>					

LIST AIRCRAFT



If a match of the AD or Inspection is found, then a list of all Aircraft with this Inspection will be displayed on the screen with the Hours to run, Due date or Due time that the Inspection becomes due for each of the listed Aircraft. The option to print this list by pressing F2 is available.

	LIST OF AIRCRAFT WITH THIS INSPECTION ————————————————————————————————————								
REG	T.T.A.F.	DATE DUE	DAYS TO RUN	TIME DUE	HOURS TO RUN	CYCLES DUE	CYCLES TO RUN	CYC. ENG1	TO RUN ENG2
AFN AFO YES LCM	13405.5 15475.9 19447.1 19787.8			13630.0 15408.0 19539.0 19837.0	224.5 -67.9 91.9 49.2	0 0 0 0		0 0 0	0 0 0 0

Pressing F2 will print the list of Aircraft with this AD or Inspection

EDIT / DELETE / INSERT NEW AD or SB

SHOW LIBRARY



By highlighting and selecting from the SUB MENU, "EDIT / DE-LETE / INSERT NEW AD or SB", the next screen is displayed. Airworthiness Directives, Service Bulletins and Other Inspections can be entered directly into the Library from here.

CAUTION



CAUTION: EDITING ANY INSPECTION FROM THE LI-BRARY WILL CHANGE IT IN THE AIRCRAFT RECORD AS WELL. USE DELETE WITH EXTREME CARE!

STALL WARNING CHECK WEAR ON MAGNETO POINTS MAGNETO COMIN	THE SEAT RAILS AND REPLACE
STALL WARNING CHECK WEAR ON MAGNETO POINTS MAGNETO COMINICATION SWITCH	HORN TEST THE SEAT RAILS AND REPLACE S INSPECTION IG IN SPEED, IMPULSE COUPLE
CHECK WEAR ON MAGNETO POINTS MAGNETO COMINICATION SWITCH	THE SEAT RAILS AND REPLACE S INSPECTION IG IN SPEED, IMPULSE COUPLE
MAGNETO POINTS MAGNETO COMIN IGNITION SWITCH	S INSPECTION G IN SPEED, IMPULSE COUPLE
MAGNETO COMIN IGNITION SWITCH	G IN SPEED, IMPULSE COUPLE
IGNITION SWITCH	·
	LUBRICATION INSPECTION
ENCINE MATOR OF	
ENGINE MAJOR O	VERHAUL
EMERGENCY EXIT	FOR CORRECT OPERATION
ALTERNATE STAT	TIC LINE AND SELECTION INSP
PRESSURE TEST/F	REPLACE AIRFRAME HOSES
PRESSURE TEST/E	REPLACE ENGINE HOSES
TESTING AND CAL	LIBRATION OF VFR INST.
TESTING AND CAI	LIBRATION OF IFR INST.
CHECK LIFEJACK	ETS FOR SERVICABILITY
VERNATHERM VA	LIVE INSPECTION/ DUAL MAGS
	ALTERNATE STAT PRESSURE TEST/I PRESSURE TEST/I TESTING AND CAI TESTING AND CAI CHECK LIFEJACK

ADD INSPECTION



Pressing **INSERT** from the above screen will prompt to **ADD** a new entry into the Library.

LOOKUP TABLE FOR DIRECTIVES, BULLETINS AND INSPECTIONS LOOKUP =	=====X163
INS TO ADD INSP. ENTER TO EDIT INSP. DEL TO DEL	LETE INSP.
AD/SB INSP. REFERENCE NUMBER DESCRIPTION OF AD/SB INSPECTION	
80-13-04 SUPERS. BY 81-06-03 ELEVATOR RUDDER & AILERON TRIM TAB 81-03-04 SUPERCEDED BY 81-06-03	
81-03-04 SUPERS. BY 81-06-03 ELEVATOR RUDDER & AILERON TRIM TAB 81-04-02 SUPERCEDED BY 82-03-02	
81-04-02 SUPERS. BY 82-03-02 FLAP LINEAR ACTUATORS	54Ns Ø1-369
81-06-02 AIRCRAFT AIRWORTHINESS DIRECTIVES - SERVICE BULLETINS 81-06-02 Record will be Added	Ns Ø1-369
81-06-03 ITEM : 565 81-06-03 AD REF :	T.BEARING
81-07-01 DESCRIP: 81-07-01	
81-10-01	
81-10-01 AIRFRAME CYCLES BETWEEN INSPECTIONS 0 81-11-03 ENGINE CYCLES BETWEEN INSPECTIONS 0	
81-11-03 L 81-11-03 SUPERS. BY 81-12-01 CONTROL COLUMN INSPECTION	-

CHANGE INSPECTION



After the new entry has been added to the Library, it will be available for selecting from the Aircraft Record. To change a current entry, press the **ENTER**> key and the record will be displayed for editing, as shown below.

AIRCRAFT AIRWORTHINESS DIRECTIVES - SERVICE BULLETINS
Record will be Changed
ITEM : 414
AD REF: 81-11-03 SUPERS. BY 81-12-01
DESCRIP: CONTROL COLUMN INSPECTION
HOURS BETWEEN INSPECTIONS 0
DAYS BETWEEN INSPECTIONS 0
AIRFRAME CYCLES BETWEEN INSPECTIONS 0
ENGINE CYCLES BETWEEN INSPECTIONS 0

Airworthiness Directive can be edited, and will change all Aircraft Records

DELETE INSPECTION



To delete an Airworthiness Directive, Service Bulletin or other Inspection from the Library of Inspections, press the **DELETE**> key while the Inspection to be deleted has been highlighted. This will prompt the user with the following message to confirm the deletion.

CAUTION



> CAUTION: DELETING RECORDS FROM THE LIBRARY WILL DELETE ALL THAT INSPECTION ACROSS THE ENTIRE FLEET. USE WITH EXTREME CARE!

Pressing <ENTER> will delete the record from the AD and Inspection Library AIRCRAFT AIRWORTHINESS DIRECTIVES - SERVICE BULLETINS
Press Enter to Delete
ITEM : 414
AD REF: 81-11-03 SUPERS. BY 81-12-01
DESCRIP: CONTROL COLUMN INSPECTION


HOURS BETWEEN INSPECTIONS 0
DAYS BETWEEN INSPECTIONS 0
AIRFRAME CYCLES BETWEEN INSPECTIONS 0
ENGINE CYCLES BETWEEN INSPECTIONS 0

COMPONENTS

COMPONENTS



By highlighting and selecting **COMPONENTS**, and pressing the **<ENTER>** key, the Menu shown below is displayed.



Selecting this Menu Item will display the entire Component list on the screen. The Components are sorted in order of **PART NUMBER** and a **LOCATE FUNCTION** enables the user to locate Components by typing the first few characters of the Part Number. To move through the Components, use the **down/up arrow** keys to move one Component at a times, or to move a screen at a time, use the **Page-Down** and **Page-up** keys.

	COMPONENTS LISTED IN ORDER OF PART NUMBER — X166 LOCATE PART NUMBER:								
"F	2" TO PRINT	"PAGE-	DOWN" FOR MORE	"E	SC" TO EXIT				
REG	PART No	SERIAL No	DAYS HOUR TO RUN TO R		ENG CYC.TO RUN ENG1 ENG2				
YES FIL FIL FIL FIL YES YES YES YES	2683 2683 3006912 3006912 3006913 3010311 3010311 30111102 30111102 30111102 3011713 3011713	171296 171296 1231 2696 1539 B0703 2734 2734 R827 R827 R827 R827 R827 16A166 23A098	75 380 1141. 867 957 102 871	7265 -44 7265 9273 2 5256					
AFM	3011713 3011713 3011713	31A456 3Y691 4D577		. 11241 . 19487 . 8188					

PRINTOUT

Pressing F2 from the Component Listing will PRINTOUT the entire listing of COMPONENTS for all the Fleet Aircraft.

CUSTOMER REPORT

CUSTOMER REPORT



By highlighting and selecting CUSTOMER LISTING, and pressing the **<ENTER>** key, the Customer file is displayed on the screen. To move through the Customers, use the down/up arrow keys or to move a screen at a time, use the Page-Down and Page-up keys.

	CUST	OMER LISTING	X168
Press F2 To Print			of Call Sign F3
NAME	CALLSIGN	ADDRESS	P/CODE
AIR FIJI LIMITED	AFM	ENGINEERING DEPT.	
AIR FIJI LIMITED	AFN	P.O BOX 1259 SUVA, FIJI. ENGINEERING DEPT.	0
AIR FIJI LIMITED	AFO	P.O BOX 1259 SUVA, FIJI. ENGINEERING DEPT.	0
AIR FIJI LIMITED	FHC	P.O BOX 1259 SUVA, FIJI. ENGINEERING DEPT.	0
AIR FIJI LIMITED	FHF	P.O BOX 1259, SUVA, FIJI. ENGINEERING DEPT.	0
AIR FIJI LIMITED	FSC	P.O BOX 1259, SUVA, FIJI. ENGINEERING DEPT.	0
		P.O BOX 1259, SUVA, FIJI.	Ø

PRINT CUSTOMERS



By pressing the "F2" HOT KEY, a printout of the CUSTOMER LIST is sent directly to the printer. This printout is shown below.



CUSTOMER NAME AND ADDRESS LISTING REPORT This Report Printed on APRIL 24, 1996								
CUST DATE NAME	ADDRESS	CITY STATE P/CODI						
7/10/95 CHEYENNE AVIATIO	N 4TH FLOOR CITY TOWERS BUILDING	SYDNEY NSW 2001						
3/05/94 GOLD COAST CHARTE	ERS HANGAR 402 EAGLE FARM	BRISBANE QLD 4000						
18/08/94 TC CLEANING SERVIC	E FLAT 1 12 DANELLA DRIVE	LEEMING WA 616						

QUIT

EXIT PROGRAM




From the Main Menu, highlighting and selecting **QUIT** by pressing **<ENTER>**, will end the program.

SECURITY

SECURITY



By highlighting and selecting **SECURITY**, and pressing the **<ENTER>** key, the the Menu shown below is displayed.



Select by pressing <ENTER>

SETUP USER





By highlighting and selecting **SETUP USER**, and pressing the **<ENTER>** key, a list of Users is displayed. This allows the administration of user access to the program. A User must be assigned to a Group. Setting up a Group is required before adding a User to the Group. Groups control the level of access to the program and Users become part of a Group.

USER ACCESS PASSWORD CONTROL								
Login Name ADMIN ADMINSTORE ASENACA GUEST TEST USER	Password ADMIN ADMINSTORE PASSWORD GUEST TEST USER	Group 50 51 99 20 60 99	Group Description AIRWORTHINESS ADMIN STORES ADMIN SYSTEM ADMINISTRATOR GUEST TEST GROUP SYSTEM ADMINISTRATOR					
<ins>=ADD</ins>	<	ENTER>=	EDIT =DELETE					

NEW USER



By highlighting and selecting a user, and pressing **<ENTER>**, the user can be edited and the Group Access changed. Pressing the **<INSERT>** key will add a **NEW** User and pressing the **** key will delete a highlighted User from the program.

Record will be Changed
USERNAME :ADMIN PASSWORD :ADMIN GROUP : 50
<esc>=EXIT</esc>

SETUP ACCESS GROUP

ACCESS GROUP




By highlighting and selecting SETUP ACCESS GROUP, and pressing the **<ENTER>** key, the Access Groups are displayed on the screen. To move through the Groups, use the down/up arrow keys or to move a screen at a time, use the Page-Down and Pageup keys.

GROUP ACCESS SETUP						
GROUP NUMBER	DESCRIPTION					
20 50 51 60 99	GUEST AIRWORTHINESS ADMIN STORES ADMIN TEST GROUP SYSTEM ADMINISTRATOR					
<f4>=CHANGE HIGHLIGHTED GROUP ACCESS</f4>						

ADD ACCESS GROUP



By pressing the **<INS>** key a new Group can be added as shown below. Pressing the **** key will remove the Group but it is recommended to remove all screens from a Group before deleting the Group.



EDIT GROUP ACCESS



By pressing the "F4" HOT KEY, the screens available to the highlighted User are displayed.

ADD ACCESS FOR GROUP -20 SCREEN DESCRIPTION Browse the Inventory File Filter Reorder Report Setup View Reorder List Display Print Reorder Listing
MENU - Customer, Freight and Suppliers List/View Customer File Update Customer Details List/View Freight Companys List/View Suppliers MENU - Parts Find 31 32 33 35 List/View Parts by Bin Location List/View Parts by Specific Bin Location Print Parts by Specific Bin Location \$ <INS>=ADD =REMOUE <ESC>=EXIT



SCREENLIBRARY



Pressing **<INS>** will open the **SCREEN LIBRARY**. Select the screen that you wish to **ADD** to the Group and press **ENTER**>. By pressing **** you are able to remove Screens from the Group. The top left of each screen has a number that is used to identify the screen in the Screen Library. The number in the Screen is pre-fixed with the letter I for Inventory for X for Maintenance.

GROUP	ACCESS	SCREEN	CONTROL	SCREEN	LOCATOR:	
	SCREEN	DESCRI	PTION			
	1				ame on Screen	
	3		: Invoice : Paute t	o Invoice		
	2 3 4 5 6 7 8 9		: Invento			
	5	Update	: Invento:	ry Items		
	6		Bin Locat			
	?	Update	Bin Loc	ations		
	8	View F	Bin Group	S		
	. 9	Update	Bin Gro	ups		
	10			tion Descr	iption	
	11	Browse	the Sup	plier File		
	12	Edit/F	idd/De Tet	e Supplier	B 4 13	
	13	Browse	the fre	ight Compa	ny Details	
	14 15		Job Cost		għt Companies	
	16		the GRN			
	17				Invoice/Job	
<u> </u>		FFIIIC	CHE GNM	LISC From .	TUA0106\00N	
<enter>=US</enter>	E					<esc>=EXIT</esc>

QUIT

EXITPROGRAM



From the Main Menu, highlighting and selecting **QUIT** by pressing **<EN**-**TER>**, will end the program.

USING THE INVENTORY PROGRAM

The Inventory Main Screen looks like this:

XTS INVENTORY CONTROL MENU

YOUR COMPANY NAME HERE

CHARGE OUT PARTS

Highlight using the arrow keys and press <ENTER> to select Menu Option.

INVENTORY MAINTENANCE

CUSTOMER

REPORTS

QUIT

Highlight Menu Option and Press ENTER

The Main Menu screen is presented with five choices. These can be selected by using the **<UP>** and **<DOWN>** arrow keys on your keyboard, then selecting the highlighted item by pressing your **<ENTER>** key.

SETUP COMPANY DETAILS

Pressing the **F2** key from the Main Screen will allow changes to be made to the Company address details. These details are used when producing REPORTS. Press **<ENTER>** to change the Invoice Data, when **OK** press escape to get back to the Main Screen.

Press Enter to change Invoice Data
Your Company name is:
YOUR COMPANY NAME HERE

Press ESCAPE when done

ENTER COMPANY DETAILS

Please enter your COMPANY DETAILS
Your INVOICE will show this information.

INVOICE

Invoiced Customer Customer's Address City State Postcode ATIN: Aircraft Owner

Date: (Invoice Date)

Send Remittance to: LYOUR COMPANY NAME HERE LENGINEERING DEPARTMENT LBOX 9999 LREGIONAL AIRPORT LPH 1236 411372 LFAX 679 400222

OK?

XTS User's Guide 35

1

П

CHARGE OUT PARTS Menu=Main\Charge Out Parts


OPEN INVOICE



		TODAY	S DATE:	31/07/99	AIRCRAFT CA	LL SIGN :
JOB No:	TOTAL	COST OF	PARTS:	\$0.0	00 JOB STA	RTED ON: / /
Part Number	r Qt	y Descri	iption		Unit Cos	t Sub Total
INS-ADD ITE	M F2-PRINT	JOB COST	F3-LIS	T SUPPLIERS	F4-INUOICE	DEL-REMOVE ITEM


OPEN INVOICE FORM

The flashing cursor is now at the JOB NUMBER line. Leaving the JOB NUMBER "0" and pressing **<ENTER>** will display a list of the JOB NUMBERS that are stored in the program.



DISPLAY AN INVOICE


Highlighting one of these jobs and pressing **ENTER** again will display the invoice details for that JOB.Using the LOCATOR and typing the JOB NUMBER at "Enter Job No:", will cause the program to quickly find the JOB NUMBER required. The column on the right shows the amount INVOICED and that it has been PRINTED to an INVOICE.



PRINT JOB COST



From the above INVOICE screen, a printout of the JOB COST can be obtained by pressing the F2 PRINT JOB COST key. The JOB COST printout contains the same information as the INVOICE without the margin added to the price of the inventory items.



SUPPLIERS LIST (GRN)



From any INVOICE, all the GRN numbers used for identifying the origin of the aircraft part, can be listed to the screen or printer. To list the Suppliers and GRN /STOCK Num berspress ${\bf F3}.$

While viewing the GRN Numbers on the screen, for the INVOICE that is current, you can press **F2** for a printout of the GRN Numbers.



Aircraft Registration: VH: AAA Job Number: 3 PART NUMBER **GRN NUMBER SUPPLIER DATE PURCHASED** 1007 12/12/94 1567-7 **AIRSPARES**

PRINTINVOICE



Pressing **F4** from the INVOICE SCREEN will prompt confirmation and send an INVOICE to the PRINTER in the following format.

Send Remittance to:



INVOICE

TRIPLE A CONTRACTORS 15 HANDOVER AVE

NORTH BONDI

NEW SOUTH WALES 2000

Attn: ENGINEERING MANAGER

Aircraft Registration:	J	ob No: 3		
Part Number Serial Number	Qty	Description	Unit Cost	Sub Total
1007	1	BOLT	45.00	45.00


TOTAL: \$45.00

DATE: 23/10/95

DISPLAY NEW INVOICE



To start a NEW INVOICE, with the flashing cursor at the "Enter Job No:_". Leave the JOB NUMBER "0" and press <ENTER> to display a list of the JOB NUMBERS that are stored in the program. Pressing the **INSERT**> key, with the list of Invoices displayed, will automatically start a NEW INVOICE.




PROCESS INVOICE



When a **NEW** Invoice is started, the program will automatically prompt for the next JOB (or INVOICE) Number. Next, you must tell the request box, the Call Sign of the Aircraft. If you press **<ENTER>** without entering a Call Sign, a list of ALL the CUSTOMER AIRCRAFT is displayed. Simply highlight the selection with the arrow keys and press **<ENTER>** to use that Aircraft.


Highlight using the arrow keys and press <ENTER> to select Aircraft or <INSERT> to enter a NEW Customer Aircraft



CUSTOMER AIRCRAFT




If the CUSTOMER AIRCRAFT is not listed, you may enter the details a NEW CUSTOMER AIRCRAFT by pressing the **<INSERT>** key while viewing the CUSTOMER AIRCRAFT table. This will display the following Customer Update Form. This means a NEW Customer can be added during the Invoice process.



INVOICEDATE




After the CUSTOMER AIRCRAFT has been added to the Invoice, the program will request the INVOICE DATE as shown next. Today's date is inserted by default and can be overwritten.



INVOICEDATE




When the INVOICE DATE has been entered into the request box, the INVOICE will be displayed with NO PARTS. An entry box is now shown so that Part information can be added to the INVOICE.





ENTER PART & QUANTITY | After entering the Part Number and Quantity, the program retrieves the remaining information from the Inventory and displays it for confirmation. Pressing **<ENTER>** will then ADD the part information to the invoice. At any time an INVOICE is displayed it can be EDITED, DELETED, GRN Numbers displayed and PRINTOUTS sent to the connected PRINTER.



INVENTORY MAINTENANCE Menu=Main\Inventory Maintenance

SELECTINVENTORY



When the highlighted item "INVENTORY MAINTENANCE" is selected from the Main Menu, pressing **<ENTER>**, will show the table below with the Inventory that the program has on the database.

F2 RE-ORDER LEVI	EL INVENTO	RY LOCATOR:	F3 TRANS	FER BINLOC
<ins> = NEW Pr</ins>	ART	 = DELETE PART	<enter> =</enter>	EDIT PART
PART No	BIN-SHELF	DESCRIPTION	IN STOCK	SELLPRICE
A1777-621 A30 ALUMI NI UM AN3-15 AN3-42A AN3-44A AN4-11A AN4-6A AN4-6A AN526C632R6 AN526C632R6 AN526C632R6 AN960-10 AN960-10 AN960-416 AN960-416 AN960-416	12-W3 01-SEE 12-D12 12-D12 03-D34 34-D5 Q4-D5 Q3- 12-AAA 12-222 Q1- 12-AAA Q2- 03- 12-88 12-12 Q2-	TINNERMAN NUT AIR FILTER PURE SHEET (NOT ALLOY) BOLT BOLT BOLT ALTERNATOR BOLT ALTERNATOR BOLT SCREW SCREW WASHER WASHER WASHER WASHER WASHER WASHER WASHER WASHER	0 10 10 5 2 2 4 3 2 100 0 30 96 0 1	1.50 36.31 2.68 10.61 4.20 5.40 5.40 6.28 6.28 6.09 6.08 6.09

VIEW/EDIT RECORD



To view or edit a Part in the Inventory, highlight an entry in the table list of Parts and press **<ENTER>**. Select one of the list by using your arrow keys to highlight the selection, or by typing the first letters of the part, then press **<ENTER>** to view the part record. The following screen will be displayed.

Any changes can be made and the Part Information updated.

```
Record will be Changed SHELF:122D QTY: 1 P
  30/08/96
                                                                               F3 TO CLEAR FIELDS
STK NO: COMPASS
                       BIN:T1
                                                                1 PART NUMBER: COMPASS
                         DATE RECEIVED: 30/08/96
DESCRIPTION: DIRECT READING MAGNETIC
                              SERIAL NO: T-12245-Y
                              ORDER NO: ON-9883Q
                        SUPPLIER: GLOBAL AIRSPARES PL
P/SLIP NO: 133233-PP
INVOICE NO: A10223
RELEASE NOTE: RN-987-WSHOP
                         FREIGHT CO: THT NATIONWIDE CON. NOTE NO: G7667877-P33
                   COST:
                                     95.00
                                                  QUOTE PRICE:
                                                                               0.00
                           × DISCOUNT:
                                                   И
                                                  35
                              × MARKUP:
                           SELL PRICE:
           LIST IN STOCK REPORTS: Y
                                              ΥN
                                                              RE-ORDER LEUEL:
                               REMARKS: NO LONGER AVAILABLE
```

ENTER NEW PART



To enter a **NEW PART** (a new Inventory Record), from the table of Parts, press **<INSERT>**, and a blank record will be displayed, ready to enter Part data.

```
F3 TO CLEAR FIELDS
  31/07/99
                                   Record will be Added
STK NO:
                     BIN:
                                               QTŸ:
                                                           PART NUMBER:
                      DATE RECEIVED:
                        DESCRIPTION:
SERIAL NO:
                           ORDER NO:
                           SUPPLIER:
                         P/SLIP NO:
INVOICE NO:
                      RELEASE NOTE:
                      FREIGHT CO:
CON. NOTE NO:
                                             QUOTE PRICE:
                 COST:
                        × DISCOUNT:
                        % MARKUP:
SELL PRICE:
          LIST IN STOCK REPORTS:
                                                        RE-ORDER LEVEL:
                            REMARKS:
```

To return to the previous screen, press **ESCAPE**>. To return to the Main Menu press **ESCAPE**> again.

DELETE RECORD




To **Delete** a Part in the Inventory, highlight an entry in the table list of Parts and press **<DELETE>**. The same screen of information that was displayed to EDIT the Part information is again displayed, but instead of the message **"Record will be Changed"** appearing at the top of the box, the message **"Press Enter to Delete"** is displayed. Pressing **<EN-TER>** will then delete that record.

RE-ORDER LEVEL



To check re-order levels press the **F2** RE-ORDER LEVEL key from the Inventory Maintenance Main Screen. The following entry allows you to specify a minimum level for your report.



PRINT REORDER LIST

Leaving the level at zero will display only those parts in the inventory that are at or below their minimum order levels. Pressing **F2** will print these Minimum Quantities.

<f2>=PRINT RE-ORDER LIST</f2>	NO ONDER HINIHOIT SI	OCK LEUEL <esc>=RETU</esc>	RN
PART NO STOCK/GRN SUPPLIER 0000000 MCKINN-44 ABROLHOS 0000000 MCKINN-49 ABROLHOS 0000000 MCKINN-DI ABROLHOS 079-00300 17830 AIRFLITE 079-00300 17830-DI AIRFLITE 105-2 105-2 108-1/2TBS 43988-98 WESTERN A 10R-1/2TBS 43988-98 WESTERN A 12 TEST ABROLHOS 303 LUBRICANT 303 303 LUBRICANT 303 303 LUBRICANT 303 303 LUBRICANT 303-23 5606 8R-1/2TBS 8R-1/2-02 WESTERN A 8R-1/2TBS 8R-1/2-12 WESTERN A 8R-1/2TBS 8R-1/2-12 WESTERN A 8R-1/2TBS 8R-1/2-12 WESTERN A 8R-1/2TBS 8R-1/2TBS WESTERN A 8R-1/2TBS WESTERN A 8R-1/2TBS WESTERN A 8R-1/2TBS WESTERN A R-1/2TBS WESTERN A R-1/2TB	AIR 1 AIR 5 AIR 6 0 0 IRMOTIVE 0 IRMOTIVE 0 AIR 10 0 IRMOTIVE 0	RE-ORDER UNDER 10 10 10 0 0 0 0 0	

TXFR BIN LOCATION



To TRANSFER any Inventory Item to a new BIN LOCATION, press **F3** From the Inventory Maintenance Main Screen. A screen will display to allow the user to define the new BIN LOCATION as well as the number of Inventory Items transfered. In addition REMARKS can be entered and the STOCK NUMBER/GRN is changed. When Inventory items are moved with the **F3** TRANSFER BIN LOCATION function, the last two characters of the GRN NUMBER are changed to indicate the BIN LOCATION they are moved to. The next Screen displays the TRANSFER BIN LOCATION function.


ENTER NEW SHELF: 0.0 ENTER NEW BIN LOCATION:
ENTER QUANTITY TO TXFR:
REMARKS A1777-621 TINNERMAN NUT PART NUMBER DESCRIPTION INSTOCK COST GRN NUMBER DATE PURCHASED WAM040297 5/02/96 QŬŎŤĒ ORDER NUMBER
SUPPLIER
PACK SLIP NO
INUOICE NO
RELEASE NOTE
FREIGHT COMPANY
CON.NOTE NO WESTERN AIRMOTIVE COURIER AUSTRALIA PREPAID LISTED IN STOCK REPORTS SERIAL NO MARGIN ADDED % DISCOUNT x RE-ORDER LEUEL

CUSTOMERS (Menu=Main\Customers

SELECT CUSTOMER



From the Main Menu, highlighting and selecting **CUSTOMERS** will display the screen below. A SUB MENU is presented with the CUSTOMERS, FREIGHT COMPANYS and SUPPLIERS records that are stored in the program.




CUSTOMERFILE



Selecting "CUSTOMER" from the SUB MENU will display a listing of the CUSTOMERS on file.

Highlight using the arrow keys or type in the name, then press <ENTER> to view or update


DELETE a record by simply highlighting and pressing <DELETE>. Your action will prompt the program to confirm the deletion



VIEW/EDIT RECORD



To display and edit the Customer file, highlight the selected customer using your arrow keys, and press **<ENTER>**. A window will appear displaying the Customer record. The cursor will be flashing in the first entry, allowing you to overwrite the information. To return to the previous Customer table screen above, press **<ESCAPE>**.



ENTER NEW RECORD




To enter a **NEW RECORD** (a new Customer record), from the table of Customers, press **<INSERT>**, and a blank record will be displayed, ready to enter Customer data. To return to the previous screen, press **<ESCAPE>**. To return to the Main Menu press **<ESCAPE>** again.

FREIGHT COMPANY FILE




Selecting "FREIGHT COMPANIES" from the SUB MENU will display a listing of the FREIGHT COMPANIES on file.



SUPPLIERS FILE



Selecting "SUPPLIERS" from the SUB MENU will display a listing of the SUPPLIERS on file.




REPORTS

REPORTS MENU



Highlighting and Selecting the "REPORTS" option from the MAIN MENU will display the following SUB MENU.



Highlight using the arrow keys and press <ENTER> to select a Menu option

Menu=MAIN\REPORTS\QUICK FIND PART

QUICK FIND MENU XXXX



PARTS QUICK FIND
BIN LOCATION
PART NUMBER
DESCRIPTION
GRN or STOCK NUMBER
FIND PART ON AIRCRAFT
<esc>=EXIT</esc>

Menu=MAIN\REPORTS\QUICK FIND PART\BIN LOCATION

PARTS QUICK FIND BINLOCATION



Highlighting and Selecting the "BIN LOCATION" option from the QUICK FIND PART MENU will display the following screen with a locator input field at the top of the screen asking for search text. After this is entered, the table will scroll to the first matching entry.

F2 PRIN	T ENTER	BIN LOCATION:	F3 TXFR BIN F4 EXPORT
BINLOC	PART No	Description	Cost Price QTY
00- 00- 00-WER 01- 01- 01- 01-SEE 02- 02- 02- 02- 02-A3 02-A4 02-A4E	C012 H0IST WE JMCRK MS24462-4 MS24665-138 MS24665-360 A30 MS28775-222 MS28775-222 MS28775-329 8R-1/2TBS 8R-1/2TBS 8R-1/2TBS 8R-1/2TBS	O RING COATES HIRE e COMPASS KIT BEARING SPLIT PIN SPLIT PINS AIR FILTER O RING - BRAKE O RING BRAKE CYL O RING SCREW SCREW SCREW	1.00 17 47.95 5 0.00 1 21.43 12 30.26 0 0.20 12 0.11 99 36.31 10 2.11 16 1.28 2 5.00 4 0.50 190 0.50 189
HIGHLIGH		NTER> TO LIST BY BIN LO	



By pressing the **F4** EXPORT key on the previous screen, a report is saved to the local directory that contains the data that was displayed in the screen. It is now possible to view this data in other software applications such as spreadsheets and word processors. The name of the EX-PORT file for BIN LOCATIONS is XLBINLOC.CSV.

		INUENTORY LISTING FOR	BIN LOCAT	ION	I.37
PART NUMBER	SHELF	DESCRIPTION	QTY	UNIT COST	TOTAL COST
303 LUBRICANT 8R-1/2TBS 8R-1/2TBS 8R-1/2TBS 8R-1/2TBS 93231565 A1777-621 ALUMINIUM AN3-15 AN4-6A AN526C632R6 AN960-10 AN960-416 AN960-416 SCAT6	A4 S6 D4 S6 AAA S33 W1 D12 D12 AAA 222 AAA 12 88 12	MOREYS SPRAY LUBRICANT SCREW SCREW SCREW SCREW CLOTH TAPE TINNERMAN NUT PURE SHEET (NOT ALLOY) BOLT ALTERNATOR BOLT SCREW WASHER WASHER WASHER SCAT HOSE	0 0 0 0 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	8.38 0.50 0.50 0.50 11.88 1.20 1.23 4.50 0.23 0.06 0.07 6.60	0.00 0.00 0.00 0.00 11.88 0.00 10.15 9.00 1.80 23.00 0.07 0.00 6.60
<f2>=PRINT</f2>		TOTAL COST \$	73.50	< I	SC>=EXIT

BIN LOCATION GROUP



Highlighting and selecting any of the Inventory Items will cause another screen to open, listing ALL items that share the same "BIN LOCA-**TION"** as the selected Inventory Item. In addition, the total cost of the items that share the selected BIN LOCATION is displayed at the bottom of the screen.

Menu=MAIN\REPORTS\QUICK FIND PART\PART NUMBER

	ENTER THE PA	RT NO TO LOCATE:		I 40
PART No SERIAL No	GRN No BIN LOC	Description	Cost Price	QTY
POPRIUET-18	CALLIGARO Ø3-	POP RIVETS	4.00	1
PREMOFLEX	PREMOFLEX B2-	BREATHER HOSE	15.10	1
RA66108	42921 D1-	BRAKE PADS	19.91	7
RIVNUT-8	3000 03-	RIVET TYPE NUT	0.20	14
S1823-3	43867 Q3-	ROD END	28.57	1
SA641250	43988 D2-	CRANKSHAFT SEAL	0.00	1
SA643967	WAM040297 B1-	EXHAUST NUT CONTINENTAL	8.55	24
SA646605	WAM040297 B2-	NUT	2.70	24
SCAT6	040796-6 12-12	SCAT HOSE	6.60	1
<esc>=BACK</esc>	<enter>=EDIT</enter>	=DELETE <f2< td=""><td>>=PRINT <f4< td=""><td>>=EXPORT</td></f4<></td></f2<>	>=PRINT <f4< td=""><td>>=EXPORT</td></f4<>	>=EXPORT

PARTS QUICK FIND **PARTNUMBER**



Highlighting and Selecting "PART NUMBER" will display the Inventory Items sorted and displayed in order of Part Number. By entering the first characters of the item, the program will automatically find the closest match. Data can be exported to XLPARTNO.CSV by pressing F4.

Menu=MAIN\REPORTS\QUICK FIND PART\DESCRIPTION

ENTER THE DESC	RIPTION TO I	OCATE:			I 4
Description	GRN No BIN LOC	PART No SERIAL No	Cost	Price	QTY
FUEL	FUEL ZZ-	FUEL		1.00	1
FUSE	FUSE 03-	FUSE		0.32	2
FUSE HOLDER	FUSE HOLD	FUSE HOLDER		1.90	0
GROMMET	070596-2 Q1-	MS35489-12		8.09	2
HYDRAULIC FLUID	5606 11-A4	5606		4.00	0
LAMP 100W	17827 AS-A4	4509		39.02	1
LARGE CABLE TIES	111096 03-	TY-WRAP-L		0.37	86
MEDIUM CABLE TIES	111096 03-	TY-WRAP-M		0.15	75
MOREYS SPRAY LUBRICANT	303 44-T654	303 LUBRICANT		8.38	0
<esc>=BACK <enter>=E</enter></esc>	DIT <de< td=""><td>L>=DELETE</td><td><f2>=PRINT</f2></td><td>⟨F4⟩=</td><td>EXPORT</td></de<>	L>=DELETE	<f2>=PRINT</f2>	⟨F4⟩=	EXPORT

PARTS QUICK FIND DESCRIPTION



Highlighting and Selecting "DESCRIPTION" will display the Inventory Items sorted and displayed in order of Description. By entering the first characters of the item, the program will automatically find the closest match. Data can be exported to XLDESCRP.CSV by pressing F4.

	LOCATE GRN NUMBER:						
GRN No	PART No	Description	Cost Price	QTY			
040796-6 070596-2 073677 073677 073677 073677 073677 073677 105-2 111096 1111 12345 17827	SCAT6 MS35489-12 DRILL 1/8 DRILL 11/64 DRILL 15/64 DRILL 3/16 DRILL 7/64 SD511 DRIVER 105-2 TY-WRAP-L TY-WRAP-M 33 GT6434 4509 MS28775-222	SCAT HOSE GROMMET DRILL BIT DRILL BIT DRILL BIT DRILL BIT DRILL BIT 90 DEGREE DRIVER BRAKE PAD RIVET LARGE CABLE TIES MEDIUM CABLE TIES 33 test newpart LAMP 100W O RING BRAKE CYL	6.60 8.09 1.70 2.90 2.91 2.91 1.52 21.00 0.04 0.37 0.15 33.00 39.02	1 2 2 3 2 2 2 1 0 86 75 33 1 1			
<f2>=PRIN</f2>	T <f3>=SE</f3>	LECT GRN RANGE	<esc>=EXIT <f4></f4></esc>	EXPORT			

Menu=MAIN\REPORTS\QUICK FIND PART\GRN or STOCK NUMBER

PARTS QUICK FIND GRN/STOCK No



Highlighting and Selecting "GRN or STOCK NUMBER" will display the Inventory Items sorted and displayed in order of GRN. By entering the first characters of the item, the program will automatically find the closest match. Data can be exported to XLGRNNUM.CSV by pressing F4.

Menu=MAIN\REPORTS\QUICK FIND PART\FIND PART ON AIRCRAFT

PARTS QUICK FIND **PARTNUMBER**



Highlighting and Selecting "FIND PART ON AIRCRAFT" will display an entry screen for the Part Number. By entering the full part number, the program will list all occurances of that part currently charged to a job or invoice. Data can be exported to XLPARTNO.CSV by pressing F4.

48 XTS User's Guide

JOB NUMBER DATE FITTED AIRCRAFT GRN NUMBER SERIAL NUMBER QTY 31/05/99 13/06/98 TEST123 TEST123 J344 AAA 1.0 1783**0** 17830 TIM AAA 1.0 13/06/98 13/06/98 17830-12 17830 AAA TIM 1.0 ZZ ZZZ TEST123 BBB17830 13/06/98 AAA 34.0 TEST123 <ESC>=EXIT <F2>=PRINT <F4>=EXPORT

ENTER PART NUMBER TO SEARCH: 079-00300

Menu=MAIN\REPORTS\SUPPLIER INDEX

SUPPLIERS



Highlighting and Selecting the "SUPPLIER INDEX" option from the REPORT MENU will display the following listing of Inventory suppliers. By highlighting and selecting one of the SUPPLIERS a listing of parts supplied by individual suppliers is displayed.

> HIGHLIGHT THE SUPPLIERS NAME TO LIST PRODUCTS OBTAINED AND PRICES PAID AIRFLITE AVIALL AIRSPARES HAWKER PACIFIC HAWLER DE HAVILLAND

SUPPLIER LISTING



By selecting a SUPPLIER from the previous screen, a listing of the Inventory Items supplied by this SUPPLIER are displayed.

SUPPLIERS NAME TOTAL COST VA		ES SUPPLII SUPPLIERS PRODUCTS HELI	ERS TELEPHONE:2129 D IN STOCK:	955 I5 \$53.10
PART/SERIAL No		Description/GRN/BIN	Cost/QTY	Item Value
DRILL 1/8		DRILL BIT	1.70	
DRILL 11/64	03	073677 03 DRILL BIT	2 2.00	\$3.40
DRILL 15/64	03	073677 03 DRILL BIT	$\begin{smallmatrix}&&3\\2.91\end{smallmatrix}$	\$6.00
	03	073677 03	2	\$5.82
DRILL 3/16	03	DRILL BIT 073677 03	2.91	\$5.82
DRILL 7/64	03	DRILL BIT 073677 03	1.52	\$3.04
MOOSS		CLAMP SS	2.72	
SD511 DRIVER	Q1	MOOSS Q1 90 DEGREE DRIVER	21.00	\$2.72
WAA036	T1	073677 T1 WIRE BRUSH	2.65	\$21.00
	T1	WAA036 T1	2	\$5.30
<esc>=BACK</esc>		<f2>=PRINT</f2>	<1	F4>=EXPORT


Menu=MAIN\REPORTS\SHOW INVOICES FOR PERIOD

SHOW INVOICES FOR PERIOD



Highlighting and selecting "SHOW INVOICES FOR PERIOD" from the REPORT MENU, will display a screen asking for the starting and ending date for the period. The default is the current month.

Enter the starting and ending search date or leave the default setting for the current month.



After accepting the default dates or entering a custom date, pressing **<ENTER>** will display those JOBs that have been invoiced. A filter can be used to display invoices for one aircraft or all aircraft across the fleet.

	10 00 11110100	0 707 4 07 4000	TO 04 (0T) (1000	I5
LISTIN	G OF INVOICE	S FOR 1/07/1998	10 31/07/1999	
NO OF	JOBS FOR PER	IOD: 7	TOTAL OF INVOICES:	\$187.88
Job No	Call-Sign	Aircraft Own	er Date Raised	Invoice Total
1234 46 56 567 H776 J344 J998	AAA BBB AAA AAA CCC AAA BBB	CIVIL AIR SERU STATEWIDE FREI CIVIL AIR SERU CIVIL AIR SERU CITY-JET CIVIL AIR SERU STATEWIDE FREI	GHT 30/07/98 ICES 31/07/98 ICES 31/05/99 31/05/99 ICES 31/05/99	0.00 0.00 187.88 0.00 0.00 0.00
<f2>=PRI</f2>	NT	Press <esc> to</esc>	Return <f4>=EXPO</f4>	RT (XLINUOIC.CSU)

Pressing F2 will print out the displayed listing. Pressing F4 will export the data to file.

Menu=MAIN\REPORTS\SHOW JOB COSTS FOR PERIOD

FOR PERIOD




the REPORT MENU, will display a screen asking for the starting and ending date for the period. The default is the current month. The same information is displayed as for the "SHOW INVOICES FOR PE-**RIOD"** except that the amounts are now calculated on actual cost not on sell price. The **F4** export function will list the data from the screen to a file called XLJOBCST.CSV.

Menu=MAIN\REPORTS\STOCKTAKE

STOCKTAKE



Highlighting and selecting "STOCKTAKE" from the REPORT MENU, will display sub menu as shown below.



Menu=MAIN\REPORTS\STOCKTAKE\STOCK REPORTS

STOCKREPORT



Highlighting and selecting "STOCK REPORTS" from the STOCKTAKE SUB MENU, will display another sub menu with the list of STOCK REPORTS.

STOCK REPORTS	163
STOCK ITEMS	
STOCK LEVEL STATUS	
LAST VARIANCE REPORT	
TOTAL INVENTORY VALUE	
<esc>=EXIT</esc>	ᆌ

Menu=MAIN\REPORTS\STOCKTAKE\STOCK REPORTS\STOCK ITEMS

STOCK ITEMS



BIN LOOK	GROUP UP:		YOUR COMP	TOCK NUMBER R ANY NAME HERE PRINTED AUG		PRINT OUT <f2>=DETAIL <f3>=SUMMARY</f3></f2>
GRP	BIN	PART NUMBER	INSTOCK	UNIT COST	LINE COST	LINE VALUE
HA HA HA HA HA HA HA HA HA	03 03 03 03 03 03 03 03 03 03	CONTACT CEMENT DEGREASER DRILL 1/8 DRILL 11/64 DRILL 15/64 DRILL 3/16 DRILL 7/64 FIBREGLASS FUSE FUSE HOLDER MEK MS20426AD5-6 MS20426AD5-7 MS20470AD4-3 MS20470AD4-4	2 2 2 2 2 2 2 6 2 0 1 50 33 100 150	3.75 4.00 1.70 2.91 2.91 1.52 23.25 0.32 1.90 0.00 0.07 0.04	7.50 8.40 3.40 6.00 5.82 5.82 3.04 137.50 0.64 0.00 4.00 0.00 7.00 6.00	7.50 8.00 4.08 7.20 6.98 6.98 3.64 139.50 0.00 9.00 9.00 7.50
HIGH	LIGHT	AND PRESS CENTER	> TO LIST	BIN GROUP	<esc>=EXIT</esc>	<f4>=EXPORT</f4>

XTS User's Guide <u>51</u>



The Detailed GRN/Stock Number Report shown on the previous screen is sorted by **BIN GROUP**. By selecting any item and pressing the **<EN-TER>** key, a further screen is displayed showing all Items sharing the selected item's **BIN GROUP**. The total cost for this BIN GROUP is calculated and displayed at the bottom of the screen.

					I65
		INVENTORY LISTING F HA = HANGAR 110	OR BIN GROUP		
PART NUMBER	BIN	DESCRIPTION	QTY	UNIT COST	TOTAL COST
A30 JMCRK MS24462-4 MS24665-138 MS24665-360 8R-1/2TBS 8R-1/2TBS 8R-1/2TBS 8R-1/2TBS 8R-1/2TBS MS28775-222 MS28775-222 MS28775-329 AN3-42A AN960-416	01 01 01 01 02 02 02 02 02 02 03	AIR FILTER COMPASS KIT BEARING SPLIT PIN SPLIT PINS SCREW SCREW SCREW SCREW SCREW O RING - BRAKE O RING BRAKE CYL O RING BOLT WASHER	10 12 0 12 99 190 189 0 0 16 2 4 2 96	36.31 21.43 30.26 0.20 0.50 0.50 0.50 2.11 1.28 8.84 0.07	363.10 257.16 0.00 2.40 10.89 95.00 94.50 0.00 0.00 33.76 2.56 20.00 17.68 6.72
CONTACT CEMENT	03	CONTACT CEMENT	2	3.75	7.50
<f2>=PRINT</f2>	· ·	TOTAL COST \$	1,194.26	·	<esc>=EXIT</esc>



By selecting any item and pressing the **ENTER**> key, a further screen is displayed showing all Items sharing the selected item's BIN LOCA-**TION.** The total for this BIN LOCATION is displayed at the bottom of the screen.

<u> </u>					I 3'
			STING FOR BIN LO R NORTH WALL	OCATION Ø1	
PART NUMBER	SHELF	DESCRIPTION	QT	Y UNIT COST	TOTAL COST
A30 JMCRK MS24462-4 MS24665-138 MS24665-360	SEE	AIR FILTER COMPASS KIT BEARING SPLIT PIN SPLIT PINS	1! 1: 1: 9:	2 21.43 0 30.26 2 0.20	363.10 257.16 0.00 2.40 10.89
<f2>=PRINT</f2>		TOTAL COST	\$ 633.	55 4	(ESC>=EXIT



By highlighting and selecting any item and pressing the **<ENTER>** key, a further screen is displayed that allows the user to edit the data contained for the selected Inventory Item.

BI N	GROUP (UP:	ING	DETAILED GRN/S YOUR COMP INVENTORY REPORT		ANY NAME HERE		PRINT OUT
GRP	BIN	PART	NUMBER	INSTOCK	UNIT COST	LINE COST	LINE VALUE
HA HA	03 03	DEGR	ACT CEMENT EASER	2 2	3.75 4.00	7.50 8.00	7.50 8.00

DETAIL REPORT



The **Detailed GRN/Stock Number Report** can produce two printed reports. **F2** will print a detail report listing all Inventory Items in order of **BIN GROUPING** and **BIN LOCATION** with each section subtotaled. At the end of the report a complete total is displayed. Pressing **F3** will produce the same report except that the individual Inventory Items are not listed and only the summary headings and total amounts are shown. By pressing **F4**, exporting the data will generate a file called XLSTKITM.CSV.

Menu=MAIN\REPORTS\STOCKTAKE\STOCK REPORTS\STOCK LEVEL STATUS

STOCK LEVEL STATUS



From the STOCK REPORTS menu, selecting STOCK LEVEL STATUS will produce the next screen. Pressing F4 will export data to a file called XLSTKLVL.CSV. Pressing F2 to print will print the Inventory Items in order of BIN GROUP. A column of the report will list the current count of items in stock. An additional spare column on the report can be used in a stocktaking operation and 'actual' count can be marked next to the printed count. This report can be used for updating any variance in the stock levels after a stocktake operation.

	STOC	KTAKE LEVEL STATUS (CURRE	ENT COUNT>		=====169
SHELF	PART NUMBER	DESCRIPTION	STOCK NO	BIN	COUNT
WER	C012 HOIST WE JMCRK MS24462-4	O RING COATES HIRE E COMPASS KIT BEARING	C012 HOIST MCKINNO-1 JMCRK 17830	00 00 00 01 01	17 5 1 12 0
SEE	MS24665-138 MS24665-360 A30 MS28775-222 MS28775-222	SPLIT PIN SPLIT PINS AIR FILTER O RING - BRAKE O RING BRAKE CYL	MS24665-1 43867 430 42921 17827	01 01 01 02 02	12 99 10 16 2
A3 A4 A4E Q12 Q4	MS28775-329 8R-1/2TBS 8R-1/2TBS 8R-1/2TBS 8R-1/2TBS 8R-1/2TBS 8R-1/2TBS AN960-416	O RING SCREW SCREW SCREW SCREW SCREW WASHER	MS28775-3 8R-1/2-02 8R-1/2-02 8R-1/2-02 8R-1/2-02 8R-1/2-02 42921	02 02 02 02 02 02 02 03	4 9 190 189 0 0 96
<esc>=</esc>	EXIT	<f2>=PRINT</f2>		<f4></f4>	EXPORT

Menu=MAIN\REPORTS\STOCKTAKE\STOCK REPORTS\LAST VARIANCE REPORT

STOCK LEVEL STATUS



From the STOCK REPORTS menu, selecting LAST VARIANCE REPORT will display the data produced from a "DO STOCKTAKE" operation. "DO STOCKTAKE" will create a list of all items in the Inventory and create a sequenced list for editing the stock levels and producing stocktaking reports. More information on "DO STOCKTAKE" is printed later in this chapter.

	UARIANCE RI	EPORT	GENER	ATED	FROM ST	OCKTAKE ON	1/08/1999	I71
PART NUMBER	GRN	він	SHELF	QTY	COUNT	COUNT	UARIANCE COST	PERCENT
CØ12	CØ12	00		17	17	0	0.00	0.00
HOIST	HOIST	00		5	5	0	0.00	0.00
WE	MCKINNO-1	00 V	/ER	1	1	0	0.00	0.00
JMCRK	JMCRK	01		12	12	0	0.00	0.00
MS24462-4	17830	01		0	0	0	0.00	0.00
MS24665-138	MS24665-1	01		12	12	0	0.00	0.00
MS24665-360	43867	01		99	99	0	0.00	0.00
A30	A30		EE	10	10	Ō	0.00	0.00
MS28775-222	42921	02		16	16	0	0.00	0.00
MS28775-222	17827	02		_ <u>2</u>	_ <u>2</u>	Ō	0.00	0.00
MS28775-329	MS28775-3	02		4	4	Ø	0.00	0.00
8R-1/2TBS	8R-1/2-02		13	Ō	Ø	Ō	0.00	0.00
8R-1/2TBS	8R-1/2-02	Ø2 6	14 1	L90	191	ī	0.50	0.53
8R-1/2TBS	8R-1/2-02	Ø2 A		189	189	Ō	0.00	0.00
8R-1/2TBS	8R-1/2-02		112	Ö	Õ	Ō	0.00	0.00
8R-1/2TBS	8R-1/2-02		4	Ō	Ø	Ō	0.00	0.00
<esc>=EXIT</esc>			<f2>=P1</f2>	RINT	VARI ANC	E	<f4< td=""><td>>=EXPORT</td></f4<>	>=EXPORT

LAST VARIANCE REPORT



The LAST VARIANCE report can be printed by pressing the F2 key or exported by pressing the F4 key, to a file called XLVARNCE.CSV. The last three columns are updated from the "DO STOCKTAKE" menu called "PROCESS COUNT". "Count" will show a variation in the actual physical count, "Cost" will show the cost variation in the actual physical count and "Percent" will show the percentage variation in the actual physical count. All variations are calculated from the data the computer holds in comparison to the data collected during a physical stocktake opera-

Menu=MAIN\REPORTS\STOCKTAKE\STOCK REPORTS\TOTAL INVENTORY VALUE

TOTAL INVENTORY VALUE



From the menu STOCK REPORTS, highlighting and selecting the menu option "TOTAL INVENTORY VALUE" will display the entire inventory, listed in order of PART NUMBER. Pressing F4 will export the Inventory to a file called XLINVENT.CSV.

				I7
INUENTORY - ENTE	R PART NO TO	LOCATE :		<f4>=EXPORT</f4>
<f2>=INUENTORY COS</f2>	TOTAL QNT	Y OF STOCK ITEMS 8,14	4 NO OF LI	NES 116
PART No	GRN No	DESCRIPTION	IN STOCK	SELL PRICE
C012 C012	C012-12 C012-88	O RING O RING	0 10	1.00 1.00
COMPASS CONTACT CEMENT	COMPASS CONTACT	DIRECT READING MAGNETIC	1	128.25 3.75
DEGREASER DRILL 1/8	DEGREASER 073677	OIL AND GREASE REMOVER DRILL BIT	2 2	4.00 2.04
DRILL 11/64 DRILL 15/64	073677 073677	DRILL BIT DRILL BIT	2 2 2 3 2 2 2	2.40 3.49
DRILL 3/16 DRILL 7/64	073677 073677	DRILL BIT DRILL BIT	2 2	3.49 1.82
FIBREGLASS FUEL	FI BREGLAS FUEL	FIBREGLASS REPAIR KIT FUEL	6 1	23.25 1.00
FUSE HOLDER	FUSE FUSE HOLD	FUSE FUSE_HOLDER	2 0 0 0	0.40 2.28
G-242 G-242	STKN01111 STKN01112	AIRCRAFT BATTERY AIRCRAFT BATTERY 2	0 0	345.00 867.00
G-242	STKN01113	BATTERY	1	100.00

54 XTS User's Guide

INVENTORY COST



Pressing the **F2** key from the previous screen, "**TOTAL INVENTORY** VALUE", the listing is displayed showing line values and calculation of the cost of the entire Inventory. Pressing F2 from this screen will print the entire Inventory including unit cost, line cost and total Inventory value.

				I7 <u>-</u>					
	INVENTORY COST PRINTOUT								
<f2>=PRINT CO</f2>	OMPLETE INVENTORY	TOTAL CO	ST PRICE	\$38,408.94					
PART NUMBER	DESCRIPTION	QNTY	UNIT COST	LINE COST					
G-242	BATTERY	1	100.00	100.00					
G-242	AIRCRAFT BATTERY	1	566.00	0.00					
GT6434		1	0.00	0.00					
HOIST	COATES HIRE	5	47.95	239.75					
JMCRK	COMPASS KIT	12	21.43	257.16					
JUBILEE	CLAMP 1 INCH	1	1.23	1.23					
MEK	SOLUENT		4.00	4.00					
MOOSS	CLAMP SS	1	2.72	2.72					
MS20426AD5-6	RIVET	50	0.00	0.00					
MS20426AD5-7	RIVET	33	0.00	0.00					
MS20470AD4-3	RIUET	100	0.07	7.00					
MS20470AD4-4	RIUET	150	0.04	6.00					
MS20470AD4-5	RIUET	135	0.04	5.40					
MS20470AD4-6	RIVET	99	0.05	4.95					
MS20470AD5-6	RIVET	100	0.00	0.00					
MS20470AD5-7	RIVET	100	0.00	0.00					
MS20470AD5-8	RIVET	100	0.00	0.00					

Menu=MAIN\REPORTS\STOCKTAKE\SET UP BIN LOCATION NAMES

BIN LOCATION NAMES



Highlighting and selecting "SET UP BIN LOCATION NAMES" from the STOCKTAKING AND REPORTING MENU, will display a list of the BIN LOCATIONS.

BIN	LOCATIONS	<f2>=PRINT</f2>
BIN	DESCRIPTION	GROUP
00	UIRTUAL STOCK	ŪΪ
01	HANGAR NORTH WALL	HA
02	INSIDE HANGAR	HA
03	CHARGED OUT	HA
11	HEAD OFFICE	AA
44	NSW HANGAR	FO
49	QLD HANGAR	AA
AS	SPARES-EGYPT	AL
B1	ISLANDER CONSUMABLES	01
B2	ISLANDER COMPONENTS	02
D1	TWIN OTTER CONSUMABLES	3 01
D2	TWIN OTTER COMPONENTS	02
E1	767 CONSUMABLES	01
E2	767 COMPONENTS	02
<1NS>=	NEW =DELETE <	(ENTER>=EDIT

BIN LOCATION NAMES



Bin locations are assigned to a BIN GROUP. BIN GROUPS further separate stock holding for higher level control. Many Bin Locations can be assigned to a Bin Group.

BIN LOCATIONS



Highlighting and selecting an item will show the item's BIN GROUP. To edit the BIN GROUP, leave the BIN GROUP field blank and press **<ENTER>**. The BIN GROUP screen will then be dispayed. If the BIN GROUP entered is a valid BIN GROUP (already exits as a BIN GROUP), then the BIN GROUP screen will not appear and the user will be returned to the BON LOCATIONS screen.

	-						-16
	BIN	LOCA	TIONS			<f2>=PRINT</f2>	الّـــ
	BIN 00		RIPTION NAL ST			GROUP VI	
		R	ecord (will be	Add	ed	—1
ı			: ŪĪRTI	JAL STO	СК		
Ī	B1			ONSUMAB		01	
	B2 D1			OMPONEN CONSUM		02 S 01	ll.
	D2	TWIN		COMPON			ll.
	E1		CONSUM		LIIIO	01	ll.
	E2		COMPON			02	_
	<iNS>=</i	NEW	<del:< td=""><td>>=DELET</td><td>E</td><td><enter>=EDIT</enter></td><td></td></del:<>	>=DELET	E	<enter>=EDIT</enter>	

BINGROUPS



New BIN GROUPS can be added or existing BIN GROUPS deleted. Highlighting a BIN GROUP and pressing **<ENTER>** will select that BIN GROUP for use. Pressing **<INS>** will add a new BIN GROUP while pressing **** will delete a BIN GROUP.

		T.000 T.011		I6
	BIN	LOCATION		BIN GROUPS
	BIN	DESCRIPT		
_	00	VIRTUAL	GROUP	DESCRIPTION
		Record	<u>ea</u>	GLOBAL RESOURCES
Ш	BT11 TAG	A T A L	AB	AUSTRALIAN RESOURCES
Ш	BIN LOC		BA	CONSUMABLE ITEMS COMPONENT ITEMS
Ш	DESCRI	GROUP:	BB BC	PERSIHABLE ITEMS
	БІМ	GNOOF.	CA	TOOLS - EQUIPMENT
	ll B1	ISLANDER	СВ	NON AUIATION STOCK
	B2	ISLANDER		
	D1	TWIN OTT		
	D2	TWIN OTT		
	<u>E1</u>	767 CONS		
	E2	767 COMP	<ins>=NEW</ins>	<pre><enter>=USE =DELETE</enter></pre>
	<ins>=</ins>	NEW (D	/ I M9 >=MEW	/EMIEK/-USE /DEL/=DELETE
	K11407-	11L11 \D.		


Menu=MAIN\REPORTS\STOCKTAKE\DO STOCKTAKE

DOSTOCKTAKE



By highlighting and selecting "DO STOCKTAKE" from the STOCKTAKE AND REPORTING menu, the following MENU screen is displayed.

<u>56</u> XTS User's Guide



Menu=MAIN\REPORTS\STOCKTAKE\DO STOCKTAKE\CREATE NEW STOCKTAKE

DOSTOCKTAKE



By highlighting and selecting "CREATE NEW STOCKTAKE" from the menu, a process is started on the computer that will list all the Inventory Items into a separate file. This file can then be used to collate additional stocktaking data. After the "CREATE NEW STOCKTAKE" has been selected, continue by selecting "PROCESS STOCK COUNT". The following screen is displayed with the results of the transfer of Inventory Item information into the separate file.

Menu=MAIN\REPORTS\STOCKTAKE\DO STOCKTAKE\PROCESS STOCK COUNT

		STOCKTAKE COUNT PR STOCKTAKE DATE: AU			I7
SHELF	PART NUMBER	DESCRIPTION	GRN 1	BIN Q	TY COUNT
WER	C012 HOIST WE	O RING COATES HIRE	CØ12 HOIST MCKINNO-1	00 : 00	17 17 5 5 1 1
	JMCRK MS24462-4 MS24665-138 MS24665-360	COMPASS KIT BEARING SPLIT PIN SPLIT PINS	JMCRK 17830 MS24665-1 43867	01 01 :	12 12 0 0 12 12 99 99
SEE	A30 MS28775-222 MS28775-222 MS28775-329	AIR FILTER O RING - BRAKE O RING BRAKE CYL O RING	A30 42921 17827 MS28775-3	02 02	10 10 16 16 2 2 4 4
A3 A4 A4E Q12	8R-1/2TBS 8R-1/2TBS 8R-1/2TBS 8R-1/2TBS 8R-1/2TBS	SCREW SCREW SCREW SCREW	8R-1/2-02 8R-1/2-02 8R-1/2-02 8R-1/2-02	02 02 19 02 19	0 0 91 191 89 189 0 0
<esc< td=""><td>>=EXIT</td><td>HIGHLIGHT F</td><td>RECORD AND PRESS</td><td><enter:< td=""><td>> TO CHANGE</td></enter:<></td></esc<>	>=EXIT	HIGHLIGHT F	RECORD AND PRESS	<enter:< td=""><td>> TO CHANGE</td></enter:<>	> TO CHANGE

STOCKTAKE COUNT **PROCESSING**



By highlighting and selecting an Inventory Item, an edit screen will be displayed that allows editing of the actual item count for creating the VARIANCE REPORT in STOCK REPORTS. By default the count will be the same as the expected quantity. If a stocktake reveals a differing count, then this new count is entered here and the Inventory is automatically reconciled as well as a VARIANCE REPORT generated.


	Record will be Changed				
PART: CØ12	GRN: CØ12 SERIAL:				
	EXPECTED QTY: 17 COUNT: 17				

Menu=MAIN\REPORTS\SECURITY

SECURITY OPTIONS



Highlighting and selecting "SECURITY" from the REPORT MENU, will display two menu choices. "SETUP USER" and SETUP ACCESS GROUP".



Menu=MAIN\REPORTS\SECURITY\SETUP USER

SETUPUSER



Highlighting and selecting "SETUP USER" from the SECURITY MENU, will display two menu choices. "SETUP USER" and SETUP ACCESS GROUP". SETUP USER displays the current users that are allowed access to the program.

USER ACCESS PASSWORD CONTROL				
Login Name	Password	Group	Group Description	
ADMIN ADMINSTORE GUEST USER	ADMIN ADMINSTORE GUEST USER	50 51 20 99	AIRWORTHINESS ADMIN STORES ADMIN GUEST SYSTEM ADMINISTRATOR	

EDITUSER



Highlighting and selecting any USER and pressing **<ENTER>** from the "USER ACCESS PASSWORD CONTROL" screen will allow editing, A new user can be added by pressing **<INS>** and a current user can be deleted by pressing ****. Users are assigned to a USER GROUP that controls the screens that the user can access.



Menu=MAIN\REPORTS\SECURITY\SETUP ACCESS GROUP

SETUP ACCESS GROUP



Highlighting and selecting "SETUP ACCESS GROUP" from the SECURITY MENU, will display the GROUPS currently setup. The GROUPS contain the access rights for the screens and USERS are members of GROUPS.

	GROUP ACCESS SETUP
GROUP NUMBER	DESCRIPTION
GROUP NUMBER 20 50 51 60 99	GUEST AIRWORTHINESS ADMIN STORES ADMIN TEST GROUP SYSTEM ADMINISTRATOR
<f4>=CHAN</f4>	GE HIGHLIGHTED GROUP ACCESS

NEW GROUP



By pressing **<INS>** a new GROUP can be added. Pressing **** will delete an existing GROUP.

GROUP ACCESS SETUP			
GROUP NUMBER DESCRIPTION			
20 GUEST			
Record will be Added			
GROUP NUMBER: 0 DESCRIPTION:			
<f4>=CHANGE HIGHLIGHTED GROUP ACCESS</f4>			

EDIT GROUP ACCESS



By pressing **F4** the highlighted GROUP can be edited to add or remove screen access. The access screens are numbered in the top right hand corner. To add a screen to a GROUP to provide access for all the users of that GROUP, use the following steps;

- 1] Press **F4** to open the GROUP screen listing
- 2] Press **<INS>** to open the library containing all the screens
- 3] Highlight the screen you wish to add to the group
- 4] Press **<ENTER>** to assign the screen to the GROUP

SCREENLIBRARY



The following screen is displayed when you press the F4 key. The list of screens that are currently accessible to the selected GROUP are displayed. To add additional screens press <INS>. To remove screens press .

	ADD ACCESS FOR GROUP - 20	
SCREEN	DESCRIPTION	
24 25 26 27 29 30 31 32 33 35 36 37 38	MENU - Customer,Freight and Suppl List/View Customer File Update Customer Details List/View Freight Companys List/View Suppliers MENU - Parts Find List/View Parts by Bin Location	ocation
<ins>=A</ins>		<esc>=EXIT</esc>

SCREENLIBRARY




When adding a screen to the GROUP, the required screen is added from a screen library. The screen library is shown below and contains all the accessible screens in the program.

GROUP AC	CESS	SCREEN (CONTROL	SCREEN	LOCATOR:	
sc	CREEN	DESCR	IPTION			
	24	Browse	e the Inc	entory Fi	le	
	25			Report S		
	26	View 1	Reorder I	ist Displ	ay .	
	27		Reorder			
	28			er Stock So		
	29				and Supplier	S
	30			omer File		
	31			r Details		
	32			ight Compai	างร	
	33	List/	View Supp	pliers		
	34				Invoices/Jobs	
	35		- Parts I			
	36			s by Bin I		
	37	List/	View Part	s by Spect	ific Bin Loca	tion
	38	Print	Parts by	, Specific	Bin Location	.۶
	39				by Bin Locat	
	40	List/	View Part	s ordered	by Part Numb	er
<enter>=USE</enter>						<esc>=EXIT</esc>

<u>60</u> XTS User's Guide

QUIT

EXIT PROGRAM



NOTES:

INDEX - INVENTORY CONTROL

CHARGE OU	T PARTS	
	OPEN EXISTING INVOICE	36
	DISPLAY GRN NUMBERS FROM INVOICE	37
	PRINT GRN NUMBERS FROM INVOICE	37
	PRINT INVOICE	38
	CREATE NEW INVOICE	38
INVENTORY	MAINTENANCE	
	VIEW/EDIT PART RECORD	41
	ENTER NEW PART	42
	DELETE PART RECORD	42
	TRANSFER BIN LOCATION	43
REPORTS		
	QUICK FIND MENU	46
	GRNLOCATION	
	FIND PART	48
	SUPPLIER INDEX	49
	INVOICES FOR PERIOD	50
	STOCK REPORTS	51
	BIN LOCATION & GROUPINGS	52
	INVENTORY VALUE	54
	STOCKTAKING	56
	EXPORT DATA FILE NAMES	
	XLBINLOC.CSV - PARTS SORTED BY BIN LOCATION	
	XLPARTNO.CSV - PARTS SORTED BY PART NUMBERS	
	XLDESCRP.CSV - PARTS SORTED BY DESCRIPTIONS	
	XLGRNNUM.CSV - PARTS SORTED BY GRN NUMBERS	
	XLFNDPRT.CSV - PART FOUND ON AIRCRAFT JOBS	
	XLSUPPLR.CSV-PARTS PER SUPPLIER	
	XLINVOIC.CSV - INVOICES FOR SELECTED PERIOD	
	XLJOBLST.CSV - JOB COSTS FOR SELECTED PERIOD	
	XLSTKITM.CSV - STOCK IN ORDER OF BIN GROUP/LOC	CATION
	XLSTKLVL.CSV - STOCK LEVEL STATUS / COUNT	
	XLVARNCE.CSV - VARIATION AFTER STOCKTAKE	
	XLINVENT.CSV - COMPLETE INVENTORY	
CUSTOMER		
	VIEW/EDIT CUSTOMER RECORD	
	ENTER NEW CLISTOMER RECORD	15

INDEX - MAINTENANCE CONTROL

AIRCRAFT		
	VIEW AIRCRAFT LIST	5
	CREATE AIRCRAFT RECORD	
	DELETE AIRCRAFT RECORD	
	VIEW OR UPDATE RECORD	
	VIEW AIRWORTHINESS DIRECTIVES	9
AIRWORTHI	NESS DIRECTIVES	
	ADDING INSPECTIONS TO AIRCRAFT RECORD	
	COST OF AIRWORTHINESS DIRECTIVES	
	CREATE NEW INSPECTIONS	
	DELETE INSPECTIONS FROM LIBRARY	
	DELETE INSPECTIONS FROM AIRCRAFT RECORD	
	LIST OCCURANCES OF AD, SB AND INSPECTIONS	2
	UPDATE AIRWORTHINESS DIRECTIVES	
	VIEW OR UPDATE AD, SB AND INSPECTIONS	9
COMPONENT	'S	
	ADDING COMPONENTS TO AIRCRAFT FILE	19
	DELETE COMPONENTS FROM AIRCRAFT FILE	
	SELECTING COMPONENTS FOR REPORT	18
	VIEW LIST OF DUE COMPONENTS	
	VIEW OR PRINT THE ENTIRE COMPONENT FILE	30
CUSTOMER		
	CREATE CUSTOMER RECORD	23
	DELETE CUSTOMER RECORD	23
	VIEW CUSTOMER LIST	31
	VIEW OR UPDATE CUSTOMER RECORD	23
SECURITY		
22001111		
	CREATE NEW USER	32
	DELETE NEW USER	32
	SETUP GROUP ACCESS	
	CHANGE GROUP ACCESS SCREEN	34
PRINTOUTS		
	AIRCRAFT HOURS, CYCLES, SCHEDULE/TIMES	
	AIRCRAFT INSPECTION, AD AND SB DATA	
	AIRCRAFT SPECIFICATION DATA	
	AIRWORTHINESS DIRECTIVE COMPLIANCE WORKSHEET	
	BLANK AIRCRAFT FORM	
	COMPONENT LISTING	
	CUSTOMER LISTING	
	FNGINE / PROPELLER / RADIO / MAINTENANCE EXPIRY TIMES	74

XTS User's Guide 63